WMB 50821
WMB 50821 S

Washing Machine

User's Manual



Document Number
2820523094_EN.indd / 07-08-12.(14:42)

BEKO

1 Important instructions for safety and environment

This section contains safety instructions that will help protect from risk of personal injury or property damage. Failure to follow these instructions shall void any warranty.

1.1 General safety

- This product can be used by children at and above 8 years old and by persons whose physical, sensory or mental capabilities were not fully developed or who lack experience and knowledge provided that they are supervised or trained on the safe usage of the product and the risks it brings out. Children must not play with the product. Cleaning and maintenance works should not be performed by children unless they are supervised by someone.
- Never place the product on a carpet-covered floor. Otherwise, lack of airflow beneath the machine will cause electrical parts to overheat. This will cause problems with your product.
- If the product has a failure, it should not be operated unless it is repaired by the Authorized Service Agent. There is the risk of electric shock!
- This product is designed to resume operating in the event of powering on after a power interruption. If you wish to cancel the programme, see "Cancelling the programme" section.
- Connect the product to a grounded outlet protected by a 16 A fuse. Do not neglect to have the grounding installation made by a qualified electrician. Our company shall not be liable for any damages that will arise when the product is used without grounding in accordance with the local regulations.
- The water supply and draining hoses must be securely fastened and remain undamaged. Otherwise, there is the risk of water leakage.
- Never open the loading door or remove the filter while there is still water in the drum. Otherwise, risk of flooding and injury from hot water will occur.
- Do not force open the locked loading door. The loading door will be ready to open just a few minutes after the washing cycle comes to an end. In case of forcing the loading door to open, the door and the lock mechanism may get damaged.
- Unplug the product when not in use.
- Never wash the product by spreading or pouring water onto it! There is the risk of electric shock!
- Never touch the plug with wet hands! Never unplug by pulling on the cable, always pull out by grabbing the plug.
- Use detergents, softeners and supplements suitable for automatic washing machines only.
- Follow the instructions on the textile tags and on the detergent package.
- The product must be unplugged during installation, maintenance, cleaning and repairing procedures.
- Always have the installation and repairing procedures carried out by the **Authorized Service Agent**. Manufacturer shall not be held liable for damages that may arise from procedures carried out by unauthorized persons.
- If the power cable is damaged, it must be replaced by the manufacturer, after sales service or a similarly qualified person (preferably an electrician) or someone designated by the importer in order to avoid possible risks.

1.2 Intended use

- This product has been designed for domestic use. It is not suitable for commercial use and it must not be used out of its intended use.
- The product must only be used for washing and rinsing of laundry that are marked accordingly.
- The manufacturer waives any responsibility arisen from incorrect usage or transportation.

1.3 Children's safety

- Packaging materials are dangerous to children. Keep packaging materials in a safe place away from reach of the children.
- Electrical products are dangerous for the children. Keep children away from the product when it is in use. Do not let them to tamper with the product. Use child lock to prevent children from intervening with the product.
- Do not forget to close the loading door when leaving the room where the product is located.
- Store all detergents and additives in a safe place away from the reach of the children by closing the cover of the detergent container or sealing the detergent package.

1.4 Package information

- Packaging materials of the product are manufactured from recyclable materials in accordance with our National Environment Regulations. Do not dispose of the packaging materials together with the domestic or other wastes. Take them to the packaging material collection points designated by the local authorities.

1.5 Disposing of the waste product

- This product has been manufactured with high quality parts and materials which can be reused and are suitable for recycling. Therefore, do not dispose the product with normal domestic waste at the end of its service life. Take it to a collection point for the recycling of electrical and electronic equipment. Please consult your local authorities to learn the nearest collection point. Help protect the environment and natural resources by recycling used products. For children's safety, cut the power cable and break the locking mechanism of the loading door so that it will be non-functional before disposing of the product.

1.6 Compliance with WEEE Directive

This appliance's packaging material is recyclable. Help recycle it and protect the environment by dropping it off in the municipal receptacles provided for this purpose. Your appliance also contains a great amount of recyclable material. It is marked with this label to indicate the used appliances that should not be mixed with other waste. This way, the appliance recycling organised by your manufacturer will be done under the best possible conditions, in compliance with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment. Contact your town hall or your retailer for the used appliance collection points closest to your home. We thank you doing your part to protect the environment.

2 Installation

Refer to the nearest Authorised Service Agent for installation of the product. To make the product ready for use, review the information in the user manual and make sure that the electricity, tap water supply and water drainage systems are appropriate before calling the Authorized Service Agent. If they are not, call a qualified technician and plumber to have any necessary arrangements carried out.

	Preparation of the location and electrical, tap water and waste water installations at the place of installation is under customer's responsibility.
	WARNİNG: Installation and electrical connections of the product must be carried out by the Authorized Service Agent. Manufacturer shall not be held liable for damages that may arise from procedures carried out by unauthorized persons.
	WARNİNG: Prior to installation, visually check if the product has any defects on it. If so, do not have it installed. Damaged products cause risks for your safety.
	Make sure that the water inlet and discharge hoses as well as the power cable are not folded, pinched or crushed while pushing the product into its place after installation or cleaning procedures.

2.1 Appropriate installation location

- Place the machine on a rigid floor. Do not place it on a long pile rug or similar surfaces.
- Total weight of the washing machine and the dryer -with full load- when they are placed on top of each other reaches to approx. 180 kilograms. Place the product on a solid and flat floor that has sufficient load carrying capacity!
- Do not place the product on the power cable.
- Do not install the product at places where temperature may fall below 0ºC.
- Place the product at least 1 cm away from the edges of other furniture.

2.2 Removing packaging reinforcement

Tilt the machine backwards to remove the packaging reinforcement. Remove the packaging reinforcement by pulling the ribbon.

2.3 Removing the transportation locks

	WARNİNG: Do not remove the transportation locks before taking out the packaging reinforcement.
	WARNİNG: Remove the transportation safety bolts before operating the washing machine! Otherwise, the product will be damaged.

1. Loosen all the bolts with a suitable spanner until they rotate freely **(C)**.
2. Remove transportation safety bolts by turning them gently.
3. Attach the plastic covers supplied in the User Manual bag into the holes on the rear panel. **(P)**



	Keep the transportation safety bolts in a safe place to reuse when the washing machine needs to be moved again in the future.
	Never move the product without the transportation safety bolts properly fixed in place!

2.4 Connecting water supply

	The water supply pressure required to run the product is between 1 to 10 bars (0.1 – 1 MPa). It is necessary to have 10 – 80 liters of water flowing from the fully open tap in one minute to have your machine run smoothly. Attach a pressure reducing valve if water pressure is higher.
	If you are going to use the double water-inlet product as a single **(cold)** water-inlet unit, you must install the supplied stopper to the hot water valve before operating the product. (Applies for the products supplied with a blind stopper group.)
	WARNİNG: Models with a single water inlet should not be connected to the hot water tap. In such a case the laundry will get damaged or the product will switch to protection mode and will not operate.
	WARNİNG: Do not use old or used water inlet hoses on the new product. It may cause stains on your laundry.

1. Connect the special hoses supplied with the product to the water inlets on the product. Red hose (left) (max. 90 ºC) is for hot water inlet, blue hose (right) (max. 25 ºC) is for cold water inlet.



	WARNİNG: Ensure that the cold and hot water connections are made correctly when installing the product. Otherwise, your laundry will come out hot at the end of the washing process and wear out.

2. Tighten all hose nuts by hand. Never use a tool when tightening the nuts.



3. Open the taps completely after making the hose connection to check for water leaks at the connection

points. If any leaks occur, turn off the tap and remove the nut. Retighten the nut carefully after checking the seal. To prevent water leakages and damages caused by them, keep the taps closed when the machine is not in use.

2.5 Connecting to the drain

- The end of the drain hose must be directly connected to the wastewater drain or to the washbasin.

WARNİNG: Your house will be flooded if the hose comes out of its housing during water discharge. Moreover, there is risk of scalding due to high washing temperatures! To prevent such situations and to ensure smooth water intake and discharge of the machine, fix the end of the discharge hose tightly so that it cannot come out.

- The hose should be attached to a height of at least 40 cm, and 100 cm at most.
- In case the hose is elevated after laying it on the floor level or close to the ground (less than 40 cm above the ground), water discharge becomes more difficult and the laundry may come out excessively wet. Therefore, follow the heights described in the figure.



- To prevent flowing of dirty water back into the machine and to allow for easy discharge, do not immerse the hose end into the dirty water or do not drive it in the drain more than 15 cm. If it is too long, cut it short.
- The end of the hose should not be bent, it should not be stepped on and the hose must not be pinched between the drain and the machine.
- If the length of the hose is too short, use it by adding an original extension hose. Length of the hose may not be longer than 3.2 m. To avoid water leak failures, the connection between the extension hose and the drain hose of the product must be fitted well with an appropriate clamp as not to come off and leak.

2.6 Adjusting the feet

WARNİNG: In order to ensure that the product operates more silently and vibration-free, it must stand level and balanced on its feet. Balance the machine by adjusting the feet. Otherwise, the product may move from its place and cause crushing and vibration problems.



1. Loosen the lock nuts on the feet by hand.
2. Adjust the feet until the product stands level and balanced.
3. Tighten all lock nuts again by hand.



WARNİNG: Do not use any tools to loosen the lock nuts. Otherwise, they will get damaged.

2.7 Electrical connection

Connect the product to a grounded outlet protected by a 16 A fuse. Our company shall not be liable for any damages that will arise when the product is used without grounding in accordance with the local regulations.

- Connection must comply with national regulations.
- Power cable plug must be within easy reach after installation.
- If the current value of the fuse or breaker in the house is less than 16 Amps, have a qualified electrician install a 16 Amp fuse.
- The voltage specified in the "Technical specifications" section must be equal to your mains voltage.
- Do not make connections via extension cables or multi-plugs.

WARNİNG: Damaged power cables must be replaced by the Authorized Service Agents.

Transportation of the product

1. Unplug the product before transporting it.
2. Remove water drain and water supply connections.
3. Drain all water that has remained in the product.
4. Install transportation safety bolts in the reverse order of removal procedure;

Never move the product without the transportation safety bolts properly fixed in place!

WARNİNG: Packaging materials are dangerous to children. Keep packaging materials in a safe place away from reach of the children.

3 Preparation

3.1 Sorting the laundry

- Sort laundry according to type of fabric, colour, and degree of soiling and allowable water temperature.
- Always obey the instructions given on the garment tags.

3.2 Preparing laundry for washing

- Laundry items with metal attachments such as, underwired bras, belt buckles or metal buttons will damage the machine. Remove the metal pieces or wash the clothes by putting them in a laundry bag or pillow case.
- Take out all substances in the pockets such as coins, pens and paper clips, and turn pockets inside out and brush. Such objects may damage the product or cause noise problem.
- Put small size clothes such as infant's socks and nylon stockings in a laundry bag or pillow case.
- Place curtains in without compressing them. Remove curtain attachment items.
- Fasten zippers, sew loose buttons and mend rips and tears.
- Wash “machine washable” or “hand washable” labeled products only with an appropriate programme.
- Do not wash colours and whites together. New, dark coloured cottons release a lot of dye. Wash them separately.
- Tough stains must be treated properly before washing. If unsure, check with a dry cleaner.
- Use only dyes/colour changers and limescale removers suitable for machine wash. Always follow the instructions on the package.
- Wash trousers and delicate laundry turned inside out.
- Keep laundry items made of Angora wool in the freezer for a few hours before washing. This will reduce pilling.
- Laundry that are subjected to materials such as flour, lime dust, milk powder, etc. intensely must be shaken off before placing into the machine. Such dusts and powders on the laundry may build up on the inner parts of the machine in time and can cause damage.

3.3 Things to be done for energy saving

Following information will help you use the product in an ecological and energy-efficient manner.

- Operate the product in the highest capacity allowed by the programme you have selected, but do not overload; see, "Programme and consumption table".
- Always follow the instructions on the detergent packaging.
- Wash slightly soiled laundry at low temperatures.
- Use faster programmes for small quantities of lightly soiled laundry.
- Do not use prewash and high temperatures for laundry that is not heavily soiled or stained.
- If you plan to dry your laundry in a dryer, select the highest spin speed recommended during washing process.
- Do not use detergent in excess of the amount recommended on the detergent package.

3.4 Initial use

Before starting to use the product, make sure that all preparations are made in accordance with the instructions in sections “Important safety instructions” and “Installation”. To prepare the product for washing laundry, perform first operation in Drum Cleaning programme. If your product is not equipped with Drum Cleaning programme, perform the Initial Use procedure in accordance with the methods described under “5.2 Cleaning the loading door and the drum” section of the user manual.



Use an anti-limescale suitable for the washing machines.

Some water might have remained in the product due to the quality control processes in the production. It is not harmful for the product.

3.5 Correct load capacity

The maximum load capacity depends on the type of laundry, the degree of soiling and the washing programme desired. The machine automatically adjusts the amount of water according to the weight of the loaded laundry.

WARNİNG: Follow the information in the “Programme and consumption table”. When overloaded, machine's washing performance will drop. Moreover, noise and vibration problems may occur.

Laundry type	Weight (g)
Bathrobe	1200
Napkin	100
Duvet cover	700
Bed Sheet	500
Pillowcase	200
Tablecloth	250
Towel	200
Hand towel	100
Evening gown	200
Underclothing	100
Men’s overalls	600
Men’s shirt	200
Men’s pajamas	500
Blouses	100

3.6 Loading the laundry

1. Open the loading door.
2. Place laundry items loosely into the machine.
3. Push the loading door to close until you hear a locking sound. Ensure that no items are caught in the door.

The loading door is locked while a programme is running. The door can only be opened a while after the programme comes to an end.

WARNİNG: In case of misplacing the laundry, noise and vibration problems may occur in the machine.

3.7 Using detergent and softener

When using detergent, softener, starch, fabric dye, bleach or limescale remover read the manufacturer's instructions on the package carefully and follow the suggested dosage values. Use measuring cup if available.

Detergent Drawer

The detergent drawer is composed of three compartments:
– (1) for prewash
– (2) for main wash
– (3) for softener
– (*) in addition, there is siphon piece in the softener compartment.



Detergent, softener and other cleaning agents

- Add detergent and softener before starting the washing programme.
- Never leave the detergent drawer open while the washing programme is running!
- When using a programme without prewash, do not put any detergent into the prewash compartment (compartment nr. "1").
- In a programme with prewash, do not put liquid detergent into the prewash compartment (compartment nr. "1").
- Do not select a programme with prewash if you are using a detergent bag or dispensing ball. Place the detergent bag or the dispensing ball directly among the laundry in the machine.
- If you are using liquid detergent, do not forget to place the liquid detergent cup into the main wash compartment (compartment nr. "2").

Choosing the detergent type

The type of detergent to be used depends on the type and colour of the fabric.

- Use different detergents for coloured and white laundry.
- Wash your delicate clothes only with special detergents (liquid detergent, wool shampoo, etc.) used solely for delicate clothes.
- When washing dark coloured clothes and quilts, it is recommended to use liquid detergent.
- Wash woolens with special detergent made specifically for woolens.

WARNİNG: Use only detergents manufactured specifically for washing machines.

WARNİNG: Do not use soap powder.

Adjusting detergent amount

The amount of washing detergent to be used depends on the amount of laundry, the degree of soiling and water hardness.

- Do not use amounts exceeding the dosage quantities recommended on the detergent package to avoid problems of excessive foam, poor rinsing, financial savings and finally, environmental protection.
- Use lesser detergent for small amounts or lightly soiled clothes.

Using softeners

Pour the softener into the softener compartment of the detergent drawer.

- Do not exceed the (>max<) level marking in the softener compartment.
- If the softener has lost its fluidity, dilute it with water before putting it in the detergent drawer.

Using liquid detergents

If the product contains a liquid detergent cup:

- Make sure that you have placed the liquid detergent cup in compartment nr. "2".
- If the liquid detergent has lost its fluidity, dilute it with water before putting in the detergent cup.



If the product does not contain a liquid detergent cup:

- Do not use liquid detergent for the prewash in a programme with prewash.
- Liquid detergent stains your clothes when used with Delayed Start function. If you are going to use the Delayed Start function, do not use liquid detergent.

Using gel and tablet detergent

Apply the following instructions when using tablet, gel and similar detergents.

- If the gel detergent thickness is fluidal and your machine does not contain a special liquid detergent cup, put the gel detergent into the main wash detergent compartment during first water intake. If your machine contains a liquid detergent cup, fill the detergent into this cup before starting the programme.
- If the gel detergent thickness is not fluidal or in the shape of capsule liquid tablet, put it directly into the drum before washing.
- Put tablet detergents into the main wash compartment (compartment nr. "2") or directly into the drum before washing.

Tablet detergents may leave residues in the detergent compartment. If you encounter such a case, place the tablet detergent between the laundry, close to the lower part of the drum in future washings.

Use the tablet or gel detergent without selecting the prewash function.

Using starch

- Add liquid starch, powder starch or the fabric dye into the softener compartment.
- Do not use softener and starch together in a washing cycle.
- Wipe the inside of the machine with a damp and clean cloth after using starch.

Using bleaches

- Select a programme with prewash and add the bleaching agent at the beginning of the prewash. Do not put detergent in the prewash compartment. As an alternative application, select a programme with extra rinse and add the bleaching agent while the machine is taking water from the detergent compartment during first rinsing step.
- Do not use bleaching agent and detergent by mixing them.
- Use just a little amount (approx. 50 ml) of bleaching agent and rinse the clothes very well as it causes skin irritation. Do not pour the bleaching agent onto the clothes and do not use it for coloured clothes.
- When using oxygen based bleaches, select a programme that washes at a lower temperature.
- Oxygen based bleaches can be used together with detergents; however, if its thickness is not the same with the detergent, put the detergent first into the compartment nr. "2" in the detergent drawer and wait until the detergent flows while the machine is taking in water. Add the bleaching agent from the same compartment while the machine is still taking in water.

Using limescale remover

- When required, use limescale removers manufactured specifically for washing machines only.

3.8 Tips for efficient washing

		Clothes			
		Light colours and whites	**Colours**	**Dark colours**	**Delicates/ Woolens/Silks**
		(Recommended temperature range based on soiling level: 40-90ºC)	(Recommended temperature range based on soiling level: cold-40ºC)	(Recommended temperature range based on soiling level: cold-40ºC)	(Recommended temperature range based on soiling level: cold-30ºC)
Soiling Level	**Heavily Soiled** (difficult stains such as grass, coffee, fruits and blood.)	It may be necessary to pre-treat the stains or perform prewash. Powder and liquid detergents recommended for whites can be used at dosages recommended for heavily soiled clothes. It is recommended to use powder detergents to clean clay and soil stains and the stains that are sensitive to bleaches.	Powder and liquid detergents recommended for colours can be used at dosages recommended for heavily soiled clothes. It is recommended to use powder detergents to clean clay and soil stains and the stains that are sensitive to bleaches. Use detergents without bleach.	Liquid detergents suitable for colours and dark colours can be used at dosages recommended for heavily soiled clothes.	Prefer liquid detergents produced for delicate clothes. Woolen and silk clothes must be washed with special woolen detergents.
	Normally Soiled (For example, stains caused by body on collars and cuffs)	Powder and liquid detergents recommended for whites can be used at dosages recommended for normally soiled clothes.	Powder and liquid detergents recommended for colours can be used at dosages recommended for normally soiled clothes. Use detergents without bleach.	Liquid detergents suitable for colours and dark colours can be used at dosages recommended for normally soiled clothes.	Prefer liquid detergents produced for delicate clothes. Woolen and silk clothes must be washed with special woolen detergents.
	Lightly Soiled (No visible stains exist.)	Powder and liquid detergents recommended for whites can be used at dosages recommended for lightly soiled clothes.	Powder and liquid detergents recommended for colours can be used at dosages recommended for lightly soiled clothes. Use detergents without bleach.	Liquid detergents suitable for colours and dark colours can be used at dosages recommended for lightly soiled clothes.	Prefer liquid detergents produced for delicate clothes. Woolen and silk clothes must be washed with special woolen detergents.

4 Operating the product

4.1 Control panel



1 - Programme Selection knob (Uppermost position On/Off)
2 - Programme Follow-up indicator
3 - Temperature Adjustment button
4 - Spin Speed adjustment button
5 - Auxiliary Function buttons
6 - Delayed Start button (in some models)
7 - Start / Pause button



4.2 Preparing the machine

Make sure that the hoses are connected tightly. Plug in your machine. Turn the tap on completely. Place the laundry in the machine. Add detergent and fabric softener.

4.3 Programme selection

Select the programme suitable for the type, quantity and soiling degree of the laundry in accordance with the "Programme and consumption table" and the temperature table below.

90°C	Heavily soiled white cottons and linens. (coffee table covers, tableclothes, towels, bed sheets, etc.)
60°C	Normally soiled, coloured, fade proof linens, cottons or synthetic clothes (shirt, nightgown, pajamas, etc.) and lightly soiled white linens (underwear, etc.)
40°C- 30°C- Cold	Blended laundry including delicate textile (veil curtains, etc.), synthetics and woolens.

Select the desired programme with the Programme Selection button.

	Programmes are limited with the highest spin speed appropriate for that particular type of fabric.
	When selecting a programme, always consider the type of fabric, colour, degree of soiling and permissible water temperature.
	Always select the lowest required temperature. Higher temperature means higher power consumption.
	For further programme details, see "Programme and consumption table"

4.4 Main programmes

Depending on the type of fabric, use the following main programmes.

• Cottons

Use this programme for your cotton laundry (such as bed sheets, duvet and pillowcase sets, towels, bathrobes, underwear, etc.). Your laundry will be washed with vigorous washing action for a longer washing cycle.

• Synthetics

Use this programme to wash your synthetic clothes (shirts, blouses, synthetic/cotton blends, etc.). It washes with a gentle action and has a shorter washing cycle compared to the Cottons programme.

For curtains and tulle, use the Synthetic 40°C programme with prewash and anti-creasing functions selected. As their meshed texture causes excessive foaming, wash the veils/ tulle by putting little amount of detergent into the main wash compartment. Do not put detergent in the prewash compartment.

• Woollens

Use this programme to wash your woolen clothes. Select the appropriate temperature complying with the tags of your clothes. Use appropriate detergents for woolens.

4.5 Additional programmes

For special cases, additional programmes are available in the machine.

	Additional programmes may differ according to the model of the machine.

• Cotton Economic

You may wash your normally soiled durable cotton and linen laundry in this programme with the highest energy and water saving compared to all other wash programmes suitable for cottons. Actual water temperature may differ from the declared cycle temperature. Programme duration may automatically be shortened during later stages of the programme if you wash less amount (e.g. ½ capacity or less) of laundry. In this case energy and water consumption will be further decreased giving you the opportunity for a more economical wash. This feature is available for certain models having remaining time display.

• BabyProtect

Use this programme to wash baby laundry, and the laundry that belongs to allergic persons. Longer heating time and an additional rinsing step provide a higher level of hygiene.

• Hand wash

Use this programme to wash your woolen/delicate clothes that bear “not machine- washable” tags and for which hand wash is recommended. It washes laundry with a very gentle washing action to not to damage clothes.

• Daily express

Use this programme to quickly wash your little amount of lightly soiled cotton clothes.

• Darkwash

Use this programme to wash your dark coloured laundry, or the coloured laundry that you do not want them get faded. Washing is performed with less mechanical movements at low temperature. It is recommended to use liquid detergent or wool shampoo for dark coloured laundry.

• Mixed 40 (Mix 40)

Use this programme to wash your cotton and synthetic clothes together without sorting them.

4.6 Special programmes

For specific applications, select any of the following programmes.

• Rinse

Use this programme when you want to rinse or starch separately.

• Spin + Drain

Use this programme to apply an additional spin cycle for your laundry or to drain the water in the machine.

Before selecting this programme, select the desired spin speed and press Start / Pause button. First, the machine will drain the water inside of it. Then, it will spin the laundry with the set spin speed and drain the water coming out of them. If you wish to drain only the water without spinning your laundry, select the Pump+Spin programme and then select the No Spin function with the help of Spin Speed Adjustment button. Press Start / Pause button.

	Use a lower spin speed for delicate laundries.

4.7 Temperature selection

Whenever a new programme is selected, the recommended temperature for the selected programme appears on the temperature indicator.
To decrease the temperature, press the Temperature Adjustment button. Temperature will decrease gradually.

If the programme has not reached the heating step, you can change the temperature without switching the machine to Pause mode.

4.8 Spin speed selection

Whenever a new programme is selected, the recommended spin speed of the selected programme is displayed on the spin speed indicator.
To decrease the spin speed, press the Spin Speed Adjustment button. Spin speed decreases gradually. Then, depending on the model of the product, "Rinse Hold" and "No Spin" options appear on the display. See "Auxiliary function selection" section for explanations of these options.

If the programme has not reached the spinning step, you can change the speed without switching the machine to Pause mode.

4.9 Programme and consumption table

EN							Auxiliary functions					
Programme		Max. Load (kg)	Programme Duration (~min)	Water Consumption (l)	Energy Consumption (kWh)	Max. Speed***	Prewash	Quick Wash	Rinse Plus	Anti-Creasing	Rinse Hold	Selectable temperature range °C
Cottons	90	5	147	66	2.25	1600	•	•	•	•	•	Cold-90
Cottons	60	5	118	66	1.45	1600	•	•	•	•	•	Cold-90
Cottons	40	5	98	66	0.85	1600	•	•	•	•	•	Cold-90
Cotton Economic	60**	5	151	47	0.85	1600	•	•	•	•	•	40-60
Daily express	90	5	88	55	1.90	1400			•		•	Cold-90
Daily express	60	5	58	55	1.00	1400			•		•	Cold-90
Daily express	30	5	28	55	0.20	1400			•		•	Cold-90
Darkwash	40	2.5	107	58	0.45	800			*		•	Cold-40
Mixed 40 (Mix 40)	40	3	115	45	0.50	800	•	•	•	•	•	Cold-40
Hand wash	30	1	43	30	0.15	600						Cold-30
Woollens	40	1.5	60	40	0.30	600			•		•	Cold-40
BabyProtect	90	5	165	85	1.90	1600	•		*		•	30-90
Synthetics	60	2.5	116	45	0.90	800	•	•	•	•	•	Cold-60
Synthetics	40	2.5	106	45	0.42	800	•	•	•	•	•	Cold-60

• Selectable
* Automatically selected, no canceling.
** Energy Label programme (EN 60456)
*** If maximum spin speed of the machine is lower then this value, you can only select up to the maximum spin speed.

	The auxiliary functions in the table may vary according to the model of your machine.
	Water and power consumption may vary subject to the changes in water pressure, water hardness and temperature, ambient temperature, type and amount of laundry, selection of auxiliary functions and spin speed, and changes in electric voltage.
	You can see the washing time of the programme you have selected on the display of the machine. It is normal that small differences may occur between the time shown on the display and the real washing time.

4.10 Auxiliary function selection

Use the following auxiliary functions according to your daily needs. Select the desired auxiliary functions before starting the programme. Furthermore, you may also select or cancel auxiliary functions that are suitable to the running programme without pressing the Start / Pause button when the machine is operating. For this, the machine must be in a step before the auxiliary function you are going to select or cancel.

If the auxiliary function cannot be selected or canceled, light of the relevant auxiliary function will blink 3 times to warn the user.

Some functions cannot be selected together. If a second auxiliary function conflicting with the first one is selected before starting the machine, the function selected first will be canceled and the second auxiliary function selection will remain active. For example, if you want to select Quick Wash after you have selected the Prewash, Prewash will be canceled and Quick Wash will remain active.

An auxiliary function that is not compatible with the programme cannot be selected. (See "Programme and consumption table")

Auxiliary Function buttons may vary according to the model of the machine.

• Prewash

A Prewash is only worthwhile for heavily soiled laundry. Not using the Prewash will save energy, water, detergent and time.

Prewash without detergent is recommended for tulle and curtains.

• Quick Wash

This function can be used in Cottons and Synthetics programmes. It decreases the washing times and also the number of rinsing steps for lightly soiled laundry.

When you select this function, load your machine with half of the maximum laundry specified in the programme table.

• Rinse Plus

This function enables the machine to make another rinsing in addition to the one already made after the main wash. Thus, the risk for sensitive skins (babies, allergic skins, etc.) to be effected by the minimal detergent remnants on the laundry can be reduced.

• Anti-Creasing

This function creases the clothes lesser when they are being washed. Drum movement is reduced and spinning speed is limited to prevent creasing. In addition, washing is done with a higher water level. Use this function for delicate laundry that creases easily.

• Rinse Hold

If you are not going to unload your clothes immediately after the programme completes, you may use rinse hold function to keep your laundry in the final rinsing water in order to prevent them from getting wrinkled when there is no water in the machine. Press Start / Pause button after this process if you want to drain the water without spinning your laundry. Programme will resume and complete after draining the water.

If you want to spin the laundry held in water, adjust the Spin Speed and press Start / Pause button.

The programme resumes. Water is drained, laundry is spun and the programme is completed.

Delayed Start (In some models only)

With the Delayed Start function the startup of the programme may be delayed up to 3, 6 or 9 hours.

Do not use liquid detergents when you set Delayed Start! There is the risk of staining of the clothes.

Open the loading door, place the laundry and put detergent, etc. Select the washing programme, temperature, spin speed and, if required, the auxiliary functions. Set the desired time by pressing the Delayed Start button. When the button is pressed once, 3 hours delayed start is selected. When the same button is pressed again, 6 hours delay is selected, and when it is pressed for the third time, 9 hours delayed start is selected. If you press the Delayed Start button once again, Delayed Start function will be canceled. Press Start / Pause button. Previous delayed start time light turns off and next delayed start time light turns on after every 3 hours. At the end of the countdown, all delayed start lights will turn off and the selected programme will start.

Additional laundry may be loaded during the delayed start period.

Changing the Delayed Start period

Press Delayed Start button. Every time the button is pressed, the period will change in 3-hour increments and the light of the selected delayed start time will turn on.

Canceling the Delayed Start function

If you want to cancel the delayed start countdown and start the programme immediately:

Set the Delayed Start period to zero (all delayed start period lights will turn off) or turn the Programme Selection knob to any programme. Thus, Delayed Start function will be canceled. The End/Cancel light flashes continuously. Then, select the programme you want to run again. Press Start / Pause button to start the programme.

4.11 Starting the programme

Press Start / Pause button to start the programme. Programme follow-up light showing the startup of the programme will turn on.

If no programme is started or no key is pressed within 1 minute during programme selection process, the machine will switch to Pause mode and the illumination level of the temperature, speed and loading door indicator lights will decrease. Other indicator lights and indicators will turn off. Once the Programme Selection knob is rotated or any button is pressed, indicator lights and indicators will turn on again.

4.12 Child Lock

Use child lock function to prevent children from tampering with the machine. Thus you can avoid any changes in a running programme.

If the Programme Selection knob is turned when the Child Lock is active, “Con” appears on the display. The Child Lock does not allow any change in the programmes and the selected temperature, speed and auxiliary functions.

Even if another programme is selected with the Programme Selection knob while the Child Lock is active, previously selected programme will continue running.

When the Child Lock is active and the machine is running, you can switch the machine to Pause mode without deactivating the Child Lock by turning the Programme Selection knob to On / Off position. When you turn the Programme Selection knob afterwards, the programme will resu

To activate the Child Lock:
Press and hold 1st and 2nd Auxiliary Function buttons for 3 seconds. The lights on the 1st and 2nd Auxiliary Function buttons will flash while you keep the buttons pressed for 3 seconds.
To deactivate the Child Lock:
Press and hold 1st and 2nd auxiliary function buttons for 3 seconds while any programme is running. The lights on the 1st and 2nd Auxiliary Function buttons will flash while you keep the buttons pressed for 3 seconds.

In addition to the method above, to deactivate the Child Lock, switch the Programme Selection knob to On / Off position when no programme is running, and select another programme.

When the power is restored after a power failure or after your machine is unplugged and plugged in again, the Child Lock will not be deactivated when the machine resumes operating.

4.13 Progress of programme
Progress of a running programme can be followed from the Programme Follow-up indicator. At the beginning of every programme step, the relevant indicator light will turn on and light of the completed step will turn off.
You can change the auxiliary functions, speed and temperature settings without stopping the programme flow while the programme is running. To do this, the change you are going to make must be in a step after the running programme step. If the change is not compatible, relevant lights will flash for 3 times.

If the machine does not pass to the spinning step, Rinse Hold function might be active or the automatic unbalanced load detection system might be activated due to the unbalanced distribution of the laundry in the machine.

4.14 Loading door lock
There is a locking system on the loading door of the machine that prevents opening of the door in cases when the water level is unsuitable.
Loading door light will start flashing when the machine is switched to Pause mode. Machine checks the level of the water inside. If the level is suitable, Loading Door light illuminates steadily within 1-2 minutes and the loading door can be opened.
If the level is unsuitable, Loading Door light turns off and the loading door cannot be opened. If you are obliged to open the Loading Door while the Loading Door light is off, you have to cancel the current programme; see "Canceling the programme".

4.15 Changing the selections after programme has started
Switching the machine to pause mode
Press the Start / Pause button to switch the machine to pause mode while a programme is running. The light of the step which the machine is in starts flashing in the Programme Follow-up indicator to show that the machine has been switched to the pause mode.
Also, when the loading door is ready to be opened, Loading Door light will also illuminate continuously in addition to the programme step light.
Changing the speed and temperature settings for auxiliary functions
Depending on the step the programme has reached, you may cancel or activate the auxiliary functions; see, "Auxiliary function selection".
You may also change the speed and temperature settings; see, "Spin speed selection" and "Temperature selection".

If no change is allowed, the relevant light will flash for 3 times.

Adding or taking out laundry
Press the Start / Pause button to switch the machine to pause mode. The programme follow-up light of the relevant step during which the machine was switched into the pause mode will flash. Wait until the Loading Door can be opened. Open the Loading Door and add or take out the laundry. Close the Loading Door. Make changes in auxiliary functions, temperature and speed settings if necessary. Press Start / Pause button to start the machine.

4.16 Canceling the programme
To cancel the programme, turn the Programme Selection knob to select another programme. Previous programme will be canceled. End / Cancel light will flash continuously to notify that the programme has been canceled.
Your machine will end the programme when you turn the Programme Selection knob; however, it does not drain the water inside. When you select and start a new programme, the newly selected programme will start depending on the step the previous programme was canceled in. For example, it may take in additional water or continue to wash with the water inside.

Depending on the step where the programme was canceled in, you may have to put detergent and softener again for the programme you have selected anew.

5 Maintenance and cleaning

Service life of the product extends and frequently faced problems decrease if cleaned at regular intervals.

5.1 Cleaning the detergent drawer

Clean the detergent drawer at regular intervals (every 4-5 washing cycles) as shown below in order to prevent accumulation of powder detergent in time.



1. Press the dotted point on the siphon in the softener compartment and pull towards you until the compartment is removed from the machine.

If more than normal amount of water and softener mixture starts to gather in the softener compartment, the siphon must be cleaned.

2. Wash the detergent drawer and the siphon with plenty of lukewarm water in a washbasin. Wear protective gloves or use an appropriate brush to avoid touching of the residues in the drawer with your skin when cleaning.
3. Insert the drawer back into its place after cleaning and make sure that it is seated well.

If your detergent drawer is the one indicated in the following figure:



Lift the rear part of the siphon to remove it as illustrated. After performing the above mentioned cleaning procedures, replace the siphon back to its seating and push its front section downwards to make sure that the locking tab engages.

5.2 Cleaning the loading door and the drum

Residues of softener, detergent and dirt may accumulate in your machine in time and may cause unpleasant odours and washing complaints. To avoid this, use the **Drum Cleaning** programme. If your machine is not featured with **Drum Cleaning** programme, use Cottons-90 programme and select **Additional Water** or **Extra Rinse** auxiliary functions as well. Run the programme without any laundry in the machine. Before starting the programme, put max. 100 g of powder anti-limescale into the main wash detergent compartment (compartment nr. 2). If the anti-limescale is in tablet form, put only one tablet into compartment nr. 2. Dry the inside of the bellow with a clean piece of cloth after the programme has come to an end.

Repeat Drum Cleaning process in every 2 months.

Use an anti-limescale suitable for the washing machines.

After every washing make sure that no foreign substance is left in the drum.



If the holes on the bellow shown in the figure is blocked, open the holes using a toothpick.

Foreign metal substances will cause rust stains in the drum. Clean the stains on the drum surface by using cleaning agents for stainless steel. Never use steel wool or wire wool.

WARNING: Never use sponge or scrub materials. These will damage the painted and plastic surfaces.

5.3 Cleaning the body and control panel

Wipe the body of the machine with soapy water or non-corrosive mild gel detergents as necessary, and dry with a soft cloth.

Use only a soft and damp cloth to clean the control panel.

5.4 Cleaning the water intake filters

There is a filter at the end of each water intake valve at the rear of the machine and also at the end of each water intake hose where they are connected to the tap. These filters prevent foreign substances and dirt in the water to enter the washing machine. Filters should be cleaned as they do get dirty.



1. Close the taps.
2. Remove the nuts of the water intake hoses to access the filters on the water intake valves. Clean them with an appropriate brush. If the filters are too dirty, take them out by means of pliers and clean them.
3. Take out the filters on the flat ends of the water intake hoses together with the gaskets and clean thoroughly under running water.
4. Replace the gaskets and filters carefully in their places and tighten the hose nuts by hand.

5.5 Draining remaining water and cleaning the pump filter

The filter system in your machine prevents solid items such as buttons, coins and fabric fibers clogging the pump impeller during discharge of washing water. Thus, the water will be discharged without any problem and the service life of the pump will extend.

If the machine fails to drain water, the pump filter is clogged. Filter must be cleaned whenever it is clogged or in every 3 months. Water must be drained off first to clean the pump filter.
In addition, prior to transporting the machine (e.g., when moving to another house) and in case of freezing of the water, water may have to be drained completely.

WARNİNG: Foreign substances left in the pump filter may damage your machine or may cause noise problem.

In order to clean the dirty filter and discharge the water:
1. Unplug the machine to cut off the supply power.

WARNİNG: Temperature of the water inside the machine may rise up to 90 ºC. To avoid burning risk, filter must be cleaned after the water in the machine cools down.

2. Open the filter cap.
   If the filter cap is composed of two pieces, press the tab on the filter cap downwards and pull the piece out towards yourself.



If the filter cap is one piece, pull the cap from both sides at the top to open.



You can remove the filter cover by slightly pushing downwards with a thin plastic tipped tool, through the gap above the filter cover. Do not use metal tipped tools to remove the cover.

3. Some of our products have emergency draining hose and some does not have. Follow the steps below to discharge the water.

Discharging the water when the product has an emergency draining hose:



a. Pull the emergency draining hose out from its seat
b. Place a large container at the end of the hose. Drain the water into the container by pulling out the plug at the end of the hose. When the container is full, block the inlet of the hose by replacing the plug. After the container is emptied, repeat the above procedure to drain the water in the machine completely.
c. When draining of water is finished, close the end by the plug again and fix the hose in its place.
d. Turn the pump filter to take it out.

Discharging the water when the product does not have an emergency draining hose:



a. Place a large container in front of the filter to catch water from the filter.
b. Loosen pump filter (anticlockwise) until water starts to flow. Fill the flowing water into the container you have placed in front of the filter. Always keep a piece of cloth handy to absorb any spilled water.
c. When the water inside the machine is finished, take out the filter completely by turning it.
4. Clean any residues inside the filter as well as fibers, if any, around the pump impeller region.
5. Install the filter.
6. If the filter cap is composed of two pieces, close the filter cap by pressing on the tab. If it is one piece, seat the tabs in the lower part into their places first, and then press the upper part to close.

6 Technical specifications

Models (EN)	WMB 50821	WMB 50821 S
Maximum dry laundry capacity (kg)	5	5
Height (cm)	84	84
Width (cm)	60	60
Depth (cm)	45	45
Net weight (±4 kg.)	59	59
Electrical input (V/Hz)	230 V / 50Hz	230 V / 50Hz
Total current (A)	10	10
Total power (W)	2200	2200
Spin speed (rpm max.)	800	800

	Technical specifications may be changed without prior notice to improve the quality of the product.
	Figures in this manual are schematic and may not match the product exactly.
	Values stated on the product labels or in the documentation accompanying it are obtained in laboratory conditions in accordance with the relevant standards. Depending on operational and environmental conditions of the product, these values may vary.

7 Troubleshooting

Programme cannot be started or selected.

• Washing machine has switched to self protection mode due to a supply problem (line voltage, water pressure, etc.). >>> *To cancel the programme, turn the Programme Selection knob to select another programme. Previous programme will be cancelled. (See "Canceling the programme")*

Water in the machine.

• Some water might have remained in the product due to the quality control processes in the production. >>> *This is not a failure; water is not harmful to the machine.*

Machine vibrates or makes noise.

• Machine might be standing unbalanced. >>> *Adjust the feet to level the machine.*
• A hard substance might have entered into the pump filter. >>> *Clean the pump filter.*
• Transportation safety bolts are not removed. >>> *Remove the transportation safety bolts.*
• Laundry quantity in the machine might be too little. >>> *Add more laundry to the machine.*
• Machine might be overloaded with laundry. >>> *Take out some of the laundry from the machine or distribute the load by hand to balance it homogenously in the machine.*
• Machine might be leaning on a rigid item. >>> *Make sure that the machine is not leaning on anything.*

Machine stopped shortly after the programme started.

• Machine might have stopped temporarily due to low voltage. >>> *It will resume running when the voltage restores to the normal level.*

Programme time does not countdown. (On models with display)

• Timer may stop during water intake. >>> *Timer indicator will not countdown until the machine takes in adequate amount of water. The machine will wait until there is sufficient amount of water to avoid poor washing results due to lack of water. Timer indicator will resume countdown after this.*
• Timer may stop during heating step. >>> *Timer indicator will not countdown until the machine reaches the selected temperature.*
• Timer may stop during spinning step. >>> *Automatic unbalanced load detection system might be activated due to the unbalanced distribution of the laundry in the drum.*
• Machine does not switch to spinning step when the laundry is not evenly distributed in the drum to prevent any damage to the machine and to its surrounding environment. Laundry should be rearranged and re-spun.

Foam is overflowing from the detergent drawer.

• Too much detergent is used. >>> *Mix 1 tablespoonful softener and ½ l water and pour into the main wash compartment of the detergent drawer.*
• Put detergent into the machine suitable for the programmes and maximum loads indicated in the "Programme and consumption table". When you use additional chemicals (stain removers, bleachs and etc), reduce the amount of detergent.

Laundry remains wet at the end of the programme

• Excessive foam might have occurred and automatic foam absorption system might have been activated due to too much detergent usage. >>> *Use recommended amount of detergent.*
• Machine does not switch to spinning step when the laundry is not evenly distributed in the drum to prevent any damage to the machine and to its surrounding environment. Laundry should be rearranged and re-spun.

WARNİNG: If you cannot eliminate the problem although you follow the instructions in this section, consult your dealer or the Authorized Service Agent. Never try to repair a nonfunctional product yourself.

لا يمكن بدء تشغيل البرنامج أو اختياره.

- انتقال الغسالة إلى وضع الحماية الذاتية بسبب مشكلة في الإمداد (على سبيل المثال جهد التيار أو ضغط الماء، وغير ذلك). <<< *لإلغاء البرنامج، أدر مقبض تحديد البرنامج لتحديد برنامج آخر. سيتم إلغاء البرنامج السابق. (انظر "إلغاء البرنامج")*

يوجد ماء في الغسالة.

- قد يتبقى بعض الماء في الغسالة نتيجة عمليات مراقبة الجودة. <<< *لا يعد هذا الأمر عطل. فالماء غير ضار بالغسالة.*

تهتز الغسالة أو تصدر ضوضاء.

- قد يكون وقوف الغسالة غير مضبوط. <<< *قم بضبط أقدام الغسالة لاستوائها.*
- قد تكون هناك مادة غريبة دخلت في فلتر المضخة. <<< *قم بتنظيف فلتر المضخة.*
- لم تتم إزالة مسامير تأمين النقل. <<< *قم بإزالة مسامير تأمين النقل.*
- قد تكون كمية الغسيل في الغسالة قليلة جدًا. <<< *قم بإضافة المزيد من الملابس.*
- قد تكون الغسالة محملة بكمية زائدة من الغسيل. <<< *أخرج بعض الغسيل من الغسالة أو وزع الحمولة باليد لموازنته في الغسالة بطريقة متجانسة.*
- الغسالة مائلة على شيئ صلب. <<< *احرص على عدم ميل الغسالة على أي شيئ.*

توقفت الغسالة بعد فترة قصيرة من بدء البرنامج.

- يمكن أن تتوقف الغسالة بشكل مؤقت نتيجة لانخفاض الجهد الكهربي. <<< *ستعاود الغسالة العمل عندما يعود الجهد إلى المعدل الطبيعي.*

العد تنازلي لوقت البرنامج لا يعمل. (الطرز التي بها شاشة)

- يمكن أن يتوقف الموقت أثناء سحب الماء. <<< *لن يقوم مؤشر الموقت بالعد التنازلي حتى تمتلئ الغسالة بالكمية المناسبة من الماء. تنتظر الغسالة حتى تتوافر الكمية المناسبة من الماء لتجنب نتائج غسيل غير مرضية بسبب نقص الماء، سوف يستأنف مؤشر الموقت العد التنازلي بعد ذلك.*
- يمكن أن يتوقف الموقت أثناء خطوة التسخين. <<< *لن يقوم مؤشر الموقت بالعد التنازلي حتى تصل الغسالة إلى درجة الحرارة المحددة.*
- يمكن أن يتوقف الموقت أثناء خطوة العصر. <<< *يمكن أن يكون قد تم تفعيل نظام الكشف التلقائي عن الحملة غير المتزنة نتيجة التوزيع غير المتوازن للملابس في الاسطوانة.*
- لا تنتقل الغسالة إلى عملية العصر عندما تكون الملابس موزعة توزيعًا غير متوازن في الاسطوانة وذلك لتجنب الإضرار بالغسالة والبيئة المحيطة بها. يجب إعادة ترتيب الملابس وإعادة عملية التدوير.

تخرج رغوة فائضة من درج المنظف.

- تم استخدام كمية كبيرة من المنظف. <<< *قم بمزج ملعقة كبيرة من المنعم مع نصف لتر ماء واسكبها في تجويف الغسيل من درج المنظف.*
- ضع المنظف في الغسالة المناسب للبرامج وللحد الأقصى من الحمولة المشار إليه في "جدول الاستهلاك والبرنامج". عند استخدام كمية إضافية من المواد الكميائية (مزيل البقع أو المبيضات ...الخ)، قم بتخفيض كمية المنظف.

تظل الملابس مبتلة في نهاية البرنامج.

- قد تظهر الرغوة الزائدة وقد يتم تنشيط نظام امتصاص الرغوة التلقائي نتيجة لاستخدام المنظف بصورة زائدة. <<< *استخدم فقط الكمية المناسبة من المنظف.*
- لا تنتقل الغسالة إلى عملية العصر عندما تكون الملابس موزعة توزيعًا غير متوازن في الاسطوانة وذلك لتجنب الإضرار بالغسالة والبيئة المحيطة بها. يجب إعادة ترتيب الملابس وإعادة عملية التدوير.

تحذير: إذا لم تتمكن من تخفيف المشكلة على الرغم من اتباع التعليمات في هذا القسم، استشر الوكيل أو مركز الخدمة المعتمد. لا تحاول إصلاح الغسالة العاطلة بنفسك مطلقًا.

الموديلات	WMB 50821	WMB 50821 S
أقصى سعة غسيل جاف (بالكيلوجرام)	5	5
الارتفاع (سم)	84	84
العرض (سم)	60	60
العمق (سم)	45	45
الوزن الصافي (+/- كجم)	59	59
التيار الكهربي (فولت/هرتز)	230 V / 50Hz	230 V / 50Hz
إجمالي التيار (بالأمبير)	10	10
الطاقة الكلية (وات)	2200	2200
سرعة الدوران (حد أقصى دورة بالساعة)	800	800

قد تخضع مواصفات هذا الجهاز للتغيير دون إخطار مسبق لأغراض تحسين جودة المنتج.

الأشكال الواردة في هذا الدليل مجرد أشكال تخطيطية وقد لا تتطابق تماماً مع المنتج الخاص بك.

تم الحصول على القيم الواردة بملصقات المنتج أو بالمراجع المرفقة به في المعمل وفقًا للمعايير ذات الصلة. وقد تختلف القيم وفقًا لظروف تشغيل الجهاز والظروف البيئية.

تحذير: قد ترتفع درجة حرارة الماء داخل الغسالة إلى 90 درجة مئوية. لتجنب خطر الحريق يجب تنظيف الفلتر بعد تبريد الماء في الغسالة.

2. افتح غطاء الفلتر.
إذا كان غطاء الفلتر مكونًا من قطعتين، اضغط على اللسان الموجود بغطاء الفلتر لأسفل واسحب القطعة للخارج باتجاهك.



إذا كان غطاء الفلتر قطعة واحدة، اسحب الغطاء من كلا الجانبين من أعلى لفتحه.



يمكنك إخراج غطاء الفلتر عن طريق الضغط برفق لأسفل بواسطة أداة بلاستيكية دقيقة عبر الفتحة أعلى غطاء الفلتر. لا تستخدم أدوات معدنية حادة لإزالة الغطاء.

3. بعض الغسالات مزودة بخرطوم تصريف طوارئ والبعض غير مزود به. اتبع الخطوات أدناه لتصريف المياه.
تصريف الماء في الغسالات المزودة بخرطوم تصريف طوارئ:



أ. اسحب خرطوم تصريف الطوارئ من مبيته
ب. ضع وعاء كبير عند طرف الخرطوم. قم بتصريف الماء جيدًا داخل الوعاء عن طريق نزع السدادة الموجودة في طرف الخرطوم. بعد امتلاء الوعاء، قم بسد مدخل الخرطوم بإعادة تركيب السدادة. وبعد تفريغ الوعاء كرر الإجراء السابق لتصريف الماء من الغسالة بالكامل.
ج. عند الانتهاء من تصريف الماء، أغلق نهاية الخرطوم بالسدادة مرة أخرى وثبت الخرطوم في مكانه.
د. شغل فلتر المضخة لسحبها للخارج.
تصريف الماء في الغسالات غير المزودة بخرطوم تصريف طوارئ:



أ. ضع وعاء كبير أمام الفلتر لاستقبال الماء المتدفق من الفلتر.
ب. قم بفك فلتر المضخة (عكس عقارب الساعة) حتى يبدأ الماء بالتدفق خارجها. ضع الماء المتدفق في الوعاء الموجود أمام الفلتر. استعمل دائمًا قطعة من القماش لامتصاص أي ماء منسكب.
ج. عند انتهاء الماء داخل الغسالة، انزع الفلتر تمامًا عن طريق تدويره.
4. قم بتنظيف أي بقايا موجودة داخل الفلتر والألياف الموجودة حول الدفاعة المروحية الخاصة بالمضخة، في حال وجود أي منها.
5. ركب الفلتر.
6. إذا كان غطاء الفلتر مكونًا من قطعتين، أغلق غطاء الفلتر بالضغط على اللسان. إذا كان الفلتر مكونا من قطعة واحدة، ضع الألسنة في الجزء السفلي في أماكنها واضغط على الجزء العلوي للإغلاق.

5 الصيانة والتنظيف

تمتد فترة خدمة الغسالة وتقل مواجه المشكلات المتكررة إذا تم تنظيفها على فترات منتظمة.

5.1 تنظيف درج المنظف

قم بتنظيف درج المنظف على فترات منتظمة (كل 4 إلى 5 دورات غسيل) كما هو موضح بالأسفل لمنع ترسب مسحوق الغسيل بمرور الوقت.



1. اضغط على الدائرة المنقطة في قسم رش الماء (السيفون) بقسم المُنعم واسحبه باتجاهك حتى يخرج هذا القسم من الغسالة.

في حالة بدء تجمع كمية من الماء والمُنعم بشكل زائد في قسم المُنعم. ينبغي تنظيف السيفون.

2. أغسل درج مسحوق الغسيل والممص بكمية وفيرة من الماء الفاتر في حوض الوجه. ارتدي القفازات الواقية أو استخدم فرشاة مناسبة لتجنب لمس البقايا الموجودة بالدرج للجلد عند التنظيف.
3. أدخل الدرج مرة أخرى في موضعه بعد التنظيف والتأكد من وضعه بصورة جيدة.

إذا كان درج المنظفات هو ذلك الموضح في الشكل التالي:



ارفع الجزء الخلفي من السيفون لإزالته كما هو موضح. بعد أداء إجراءات التنظيف المذكورة أعلاه. قم بإعادة السيفون مرة أخرى إلى مكانه وادفع الجزء الأمامي منه إلى أسفل للتأكد من تركيب مقبض القفل.

5.2 تنظيف باب التحميل والأسطوانة

يمكن أن تتجمع بقايا المنعم والمنظف والأوساخ في الغسالة مع الوقت وقد تتسبب في روائح كريهة ومشكلات الغسيل. ولتجنب هذا، استخدم برنامج تنظيف الاسطوانة. إذا كانت الغسالة غير مجهزة ببرنامج تنظيف الاسطوانة، استخدم البرنامج "قطن90-" وحدد الوظيفتين الإضافيتين ماء إضافي أو شطف إضافي أيضًا. قم بتشغيل البرنامج مع عدم وضع غسيل في الغسالة. قبل بدء البرنامج، ضع 100 جم من بحد أقصى مسحوق مضاد الرواسب في تجويف المنظف الرئيسي (قسم رقم 2). إذا كان مضاد الرواسب في شكل أقراص، ضع قرص واحد فقط في القسم رقم. 2. قم بتجفيف الجزء الداخلي لرئة المروحة باستخدام قطعة نظيفة من القماش بعد انتهاء البرنامج.

كرر عملية تنظيف الاسطوانة كل شهرين.

استخدم مضاد الرواسب المناسب للغسالات.

تأكد من عدم ترك أي مواد غريبة في الاسطوانة بعد كل غسلة.



في حالة انسداد الفتحة السفلية المبينة في الشكل، فافتح الفتحة باستخدام خلة أسنان.

ستتسبب جسيمات المعادن الغريبة في حدوث بقع الصدأ في الاسطوانة. نظف البقع على سطح الاسطوانة باستخدام مواد تنظيف الصلب الذي لا يصدأ. ولا تستخدم مطلقًا الليف المعدني أو السلكي.

تحذير: لا تستخدم الإسفنج أو المواد الكاشطة مطلقًا. فقد تتسبب هذه المواد في إلحاق أضرار بالأسطح المطلية والبلاستيكية.

5.3 تنظيف جسم الغسالة ولوحة التحكم

امسح جسم الغسالة بالماء والصابون أو منظف جل متعادل لا يسبب التآكل في حالة الضرورة، وجففه بقطعة قماش ناعمة.
استخدم فقط قطعة قماش ناعمة ورطبة لتنظيف لوحة التحكم.

5.4 تنظيف فلترات مدخل الماء

يوجد فلتر في طرف كل صمام من صمامات سحب الماء عند الجزء الخلفي من الغسالة وأيضًا في طرف كل خرطوم من خراطيم سحب الماء المتصلة بالصنبور. تعمل هذه الفلاتر على منع المواد الغريبة والأوساخ الموجودة في الماء من دخول الغسالة. وينبغي تنظيف الفلاتر عندما تتسخ.



1. أغلق الصنابير.
2. فك صواميل خراطيم سحب الماء للوصول إلى الفلاتر في صمامات سحب الماء. قم بتنظيفها باستخدام فرشاة مناسبة. في حالة اتساخ الفلاتر بشدة، أخراجها بكماشة وقم بتنظيفها.
3. أخرج الفلاتر الموجودة على الأطراف المسطحة لخراطيم سحب الماء بحشياتها وقم بتنظيفها بالكامل باستخدام ماء مندفع.
4. أعد تركيب الحشيات والفلاتر بعناية في أماكنها وأحكم ربط صواميل الخرطوم باليد.

5.5 تصريف الماء المتبقي وتنظيف فلتر المضخة

يعمل نظام الفلتر بالغسالة على منع مرور الشوائب الصلبة مثل الأزرار والعملات والأنسجة العالقة خلال المضخة أثناء تصريف ماء الغسيل. لذا، يتم تصريف الماء دون ظهور أية مشكلة ويطول عمر خدمة المضخة.
إذا فشلت الغسالة في تصريف الماء، فقد يكون فلتر المضخة مسدودًا. ويجب تنظيف الفلتر في حالة انسداده أو كل 3 أشهر. ينبغي تصريف الماء بالكامل أولاً من أجل تنظيف فلتر المضخة.
بالإضافة لذلك، قبل نقل الغسالة (على سبيل المثال، عند نقلها إلى منزل آخر) وفي حالة تجمد الماء، يجب تصريف الماء تمامًا.

تحذير: يمكن أن تتسبب المواد الغريبة المتبقية في فلتر المضخة في تلف الغسالة أو تتسبب في مشكلة الضوضاء.

لتنظيف الفلاتر المتسخة وتصريف الماء:

1. افصل قابس الغسالة من مصدر التيار.

حتى في حالة تحديد برنامج آخر باستخدام مقبض اختيار البرنامج أثناء تفعيل قفل الأطفال، فسوف يستمر تشغيل البرنامج المحدد مسبقًا.

عند تفعيل قفل الأطفال أثناء تشغيل الغسالة، يمكنك تبديل الغسالة إلى وضع Pause الإيقاف المؤقت دون إلغاء تفعيل قفل الأطفال عن طريق إدارة مقبض تحديد البرنامج إلى وضع On / Off (إيقاف / تشغيل). عند إدارة مقبض تحديد البرنامج بعد ذلك، فسوف يستأنف تشغيل البرنامج.

لتفعيل قفل التأمين ضد عبث الأطفال:
اضغط مطولاً على زري الوظيفة الإضافية الأول والثاني لمدة 3 ثوان. ستومض الأضواء على زري الوظيفة الإضافية الأول والثاني أثناء الضغط مطولاً على الزرين لمدة 3 ثوان.
لإلغاء تفعيل قفل الأطفال:
اضغط مطولاً على زري الوظيفة الإضافية الأول والثاني لمدة 3 ثوان. ستومض الأضواء على زري الوظيفة الإضافية الأول والثاني أثناء الضغط مطولاً على الزرين لمدة 3 ثوان.

بالإضافة إلى الطريقة السابقة، لإلغاء تفعيل قفل الأطفال، أدر مقبض تحديد البرنامج إلى وضع "On/Off" (تشغيل/إيقاف التشغيل) في حالة عدم تشغيل أي برنامج. وحدد برنامج آخر.

عند استعادة الطاقة بعد انقطاع التيار الكهربي أو بعد فصل الطاقة عن الغسالة وتوصيلها مرة أخرى، لن يتم إلغاء قفل الأطفال عند استئناف تشغيل الغسالة.

4.13 تقدم البرنامج
يمكن متابعة تقدم البرنامج الجاري تشغيله من خلال مؤشر متابعة البرنامج. في بداية كل خطوة من خطوات البرنامج، يضيء ضوء المؤشر ذو الصلة وينطفئ ضوء الخطوة المكتملة.
يمكنك تغيير الوظائف الإضافية، وإعدادات السرعة ودرجة الحرارة بدون إيقاف سير البرنامج أثناء تشغيل البرنامج. للقيام بهذا، يجب أن يكون التغيير الذي ستقوم به في خطوة بعد خطوة البرنامج الجاري تشغيله. إذا كان التغيير غير متوافق، فسوف تومض الأضواء ذات الصلة 3 مرات.

إذا لم تنتقل الغسالة لخطوة العصر، فقد تكون وظيفة إيقاف الشطف مفعلة أو تم تنشيط نظام الكشف التلقائي عن الحمولة غير المتوازنة بسبب التوزيع غير المتوازن للملابس في الغسالة.

4.14 قفل باب التحميل
يوجد نظام قفل في باب التحميل للغسالة مما يمنع فتح الباب عندما يكون مستوى الماء غير مناسب.
سيبدأ مصباح باب التحميل في الوميض عد انتقال الغسالة إلى وضع الإيقاف المؤقت. تفحص الغسالة مستوى الماء بالداخل. إذا كان المستوى مناسبًا، يضيء مصباح باب التحميل باستمرار من 1 إلى 2 دقيقة ويمكن فتح باب التحميل.
إذا كان المستوى غير مناسب، ينطفئ مصباح باب التحميل ولا يمكن فتح باب التحميل. في حالة الاضطرار إلى فتح باب التحميل أثناء انطفاء مصباح باب التحميل، يجب إلغاء البرنامج الحالي؛ راجع "إلغاء البرنامج".

تغيير التحديدات بعد بدء تشغيل البرنامج
انتقال الغسالة إلى وضع الإيقاف المؤقت
اضغط على زر Start/Pause (بدء/إيقاف مؤقت) لتحويل الغسالة إلى وضع الإيقاف المؤقت أثناء تشغيل البرنامج. يبدأ مصباح الخطوة التي تقوم الغسالة بتنفيذها في الوميض في مؤشر متابعة البرنامج ليبان أن الغسالة قد انتقلت إلى وضع الإيقاف المؤقت.
أيضًا عندما يكون باب التحميل جاهزًا للفتح، يضيء مصباح الباب باستمرار بالإضافة إلى مصباح خطوة البرنامج.
تغيير إعدادات السرعة ودرجة الحرارة للوظائف الإضافية
بناء على الخطوة التي وصل إليها البرنامج، يمكنك إلغاء الوظائف الإضافية أو تفعيلها؛ راجع، "تحديد الوظيفة الإضافية".
يمكنك أيضًا تغيير إعدادات السرعة ودرجة الحرارة؛ راجع، "تحديد سرعة العصر" و "تحديد درجة الحرارة".

في حالة عدم السماح بالتغيير، فسوف يومض الضوء ذو الصلة 3 مرات.

4.15 إضافة الغسيل وإخراجه
اضغط على الزر Start/Pause (بدء التشغيل/الإيقاف المؤقت) للعمل على انتقال الغسالة إلى وضع الإيقاف المؤقت. سوف يومض مصباح متابعة الخطوة ذات الصلة التي تم خلالها تحويل الغسالة إلى وضع الإيقاف المؤقت. انتظر حتى يمكن فتح باب التحميل. افتح باب التحميل وأضف الغسيل أو أخرجه. أغلق باب التحميل. قم بالتغييرات في الوظائف الإضافية، أعدادات درجة الحرارة والسرعة عند اللزوم.
اضغط على الزر Start/Pause (بدء/توقف مؤقت) لبدء تشغيل الغسالة.

4.16 إلغاء البرنامج
لإلغاء البرنامج، أدر مقبض تحديد البرنامج لتحديد برنامج آخر. سيتم إلغاء البرنامج السابق. يومض مصباح End/Cancel (إنهاء/إلغاء) باستمرار للإشارة إلى إلغاء البرنامج.
ستوقف الغسالة البرنامج عند إدارة مقبض تحديد البرنامج؛ ومع ذلك، لن يتم تصريف الماء الذي بداخل الغسالة. عند تحديد برنامج جديد وبدء تشغيله، فسوف يبدأ البرنامج المحدد حديثًا بناء على الخطوة التي تم إلغاء البرنامج الآخر فيها. على سبيل المثال، فقد يسحب ماءً إضافيًا للاستمرار في الغسيل بالماء الموجود بداخل الغسالة.

بناء على الخطوة التي تم إلغاء البرنامج فيها، فقد يتوجب عليك إضافة المنظف والمنعم مرة أخرى للبرنامج الجديد الذي تم تحديده.

4.10 اختيار الوظائف الإضافية

استخدم الوظائف الإضافية التالية وفقًا لاحتياجاتك اليومية. قم بتحديد الوظائف الإضافية المطلوبة قبل بدء تشغيل البرنامج. علامة على ذلك، يمكنك أيضًا اختيار أو إلغاء الوظائف الإضافية المناسبة للبرنامج قيد التشغيل بدون ضغط زر "Start/Pause" (بدء/توقف مؤقت) عند تشغيل الغسالة. لذا، يجب أن تكون الغسالة في خطوة قبل الوظيفة الإضافية التي تريد تحديدها أو إلغائها.

في حالة تعذر اختيار أو إلغاء الوظيفة المساعدة، سوف يومض المصباح الخاص بالوظيفة الإضافية المتعلقة ثلاث مرات لتحذير المستخدم.

بعض الوظائف لا يمكن تحديدها معًا. عند اختيار وظيفة إضافية ثانية تتعارض مع الوظيفة الأولى قبل تشغيل الغسالة، فستقوم الغسالة بإلغاء الوظيفة الأولى بينما تستمر الوظيفة الثانية في العمل. على سبيل المثال، إذا تم تحديد وظيفة الغسل السريع بعد تحديد وظيفة الغسلة التحضيرية، يتم إلغاء وظيفة الغسلة التحضيرية وتبقى وظيفة الغسل السريع عاملة.

لا يمكن تحديد وظيفة إضافية لا تتوافق مع البرنامج الذي تم تحديده. (راجع "جدول البرامج والاستهلاك")

قد تختلف الوظائف الإضافية في الجدول وفقًا لطراز الغسالة.

• الغسيل المبدئي

تنطوي عملية الغسلة التحضيرية على فائدة حقيقية فقط مع الملابس شديدة الاتساخ. يؤدي عدم استخدام الغسلة التحضيرية إلى توفير الطاقة والماء ومسحوق الغسيل والوقت.

يوصى باستخدام وظيفة الغسلة التحضيرية بدون منظف مع الأربطة والستائر.

• الغسيل السريع

يمكن استخدام هذه الوظيفة لبرامج Cottons الملابس القطنية و Synthetics الألياف الصناعية. حيث تقلل من وقت الغسيل وأيضًا تقلل من عدد خطوات الشطف للغسيل قليل الاتساخ.

عند تحديد هذه الوظيفة، قم بتحميل الغسالة بنصف كمية الملابس القصوى المحددة في جدول البرامج.

• الشطف المضاعف

تتيح هذه الوظيفة للغسالة القيام بشطف إضافي فضلاً عن الشطف الذي يتم بالفعل بعد عملية الغسيل الرئيسية. بالتالي، يتم تخفيف المخاطر على الجلد الحساس (الأطفال، وجلد الأشخاص المصابين بالحساسية وغيره) والتي تتأثر بالبقايا القليلة من مسحوق التنظيف في حمولة الغسيل.

• ضد التجعيد

تقلل هذه الوظيفة من تجعيد الملابس أثناء الغسيل. تقل حركة الاسطوانة وسرعة العصر لتجنب التجعد. بالإضافة إلى هذا، تتم عملية الغسيل بمستوى مرتفع من الماء. استخدم هذه الوظيفة للملابس الرقيقة التي تتجعد بسهولة.

• إيقاف الشطف

إذا لم تكن ترغب في تفريغ حمولة الملابس بعد انتهاء البرنامج مباشرة، يمكنك استخدام وظيفة تعليق الشطف والإبقاء على الملابس في مياه الشطف الأخيرة لتجنب تجعد الملابس بسبب عدم وجود ماء في الغسالة. اضغط على زر "Start/Pause" (بدء/توقف مؤقت) بعد هذه العملية إذا أردت تصريف الماء دون عصر الغسيل. يستمر البرنامج في العمل ويكتمل بعد تصريف الماء فقط.

إذا كنت تريد إيقاف عصر الغسيل في الماء، اضبط Spin Speed (سرعة العصر) واضغط زر Start / Pause (بدء / إيقاف مؤقت).

يتم استكمال البرنامج. يتم تصريف الماء، ويتم عصر الغسيل واكتمال البرنامج.

البدء المتأخر (في بعض الطرازات فقط)

مع وظيفة البدء المتأخر يمكن تأخير بداية البرنامج ما يصل إلى 3 أو 6 أو 9 ساعات.

لا تستخدم منظفات سائلة عند ضبط البدء المتأخر! فهناك مخاطر من حدوث بُقع بالملابس.

افتح باب التحميل، وأدخل الغسيل وضع المنظف ثم حدد برنامج الغسيل ودرجة الحرارة وسرعة العصر وحدد الوظائف الإضافية إذا كان ذلك مطلوبًا. حدد الوقت المطلوب عن طريق الضغط على الزر Delayed Start (البدء المتأخر). عند الضغط على الزر مرة واحدة، يتم اختيار تأخير 3 ساعات. عند الضغط على نفس الزر مرة أخرى، يتم اختيار تأخير 6 ساعات، وإذا تم الضغط عليه مرة أخرى، سيتم اختيار تأخير 9 ساعات. في حالة الضغط على زر البدء المتأخر Delayed Start مرة أخرى، سيتم إلغاء وظيفة Delayed Start (البدء المتأخر). اضغط على الزر /Start Pause (بدء/توقف مؤقت). يتم إطفاء ضوء وقت البدء المتأخر السابق ويتم تشغيل ضوء وقت البدء المتأخر التالي كل 3 ساعات. في نهاية العد التنازلي، سيتم إطفاء جميع أضواء البدء المتأخر ويبدأ البرنامج المحدد.

يمكن تحميل ملابس إضافية أثناء فترة بدء التشغيل المؤجل.

تغيير فترة البدء المتأخر

اضغط على زر Delayed Start (البدء المتأخر). في كل مرة يتم فيها الضغط على الزر، تتغير المدة بزيادة 3 ساعات ويتم تشغيل ضوء وقت البدء المتأخر المحدد.

إلغاء وظيفة البدء المتأخر

إذا كنت ترغب في إلغاء العد التنازلي للبدء المتأخر وبدء تشغيل البرنامج في الحال:

اضبط وظيفة تأخير الوقت على القيمة صفر (تنطفئ جميع أضواء البدء المتأخر) أو حرك مقبض اختيار البرامج إلى أي برنامج. وبذلك، يتم إلغاء وظيفة البدء المتأخر. يومض ضوء End/Cancel (إنهاء/إلغاء) باستمرار. بعد ذلك، حدد البرنامج الذي تريد تشغيله مرة أخرى. اضغط على زر "Start/Pause" (بدء التشغيل / الإيقاف المؤقت) لبدء تشغيل البرنامج.

4.11 بدء تشغيل البرنامج

اضغط على زر "Start/Pause" (بدء التشغيل / الإيقاف المؤقت) لبدء تشغيل البرنامج. يضيء ضوء متابعة البرنامج ليشير إلى بدء تشغيل البرنامج.

في حالة عدم بدء أي برنامج، أو عدم الضغط على أي مفتاح في غضون 1 دقيقة أثناء عملية تحديد البرنامج، تتحول الغسالة إلى وضع Pause (الإيقاف المؤقت) ويتراجع مستوى إضاءة مؤشرات الحرارة والسرعة والباب. وتنطفئ الأضواء والمؤشرات الأخرى. بمجرد تحريك مقبض اختيار البرامج أو الضغط على أي زر، يتم تشغيل أضواء المؤشر والمؤشرات مرة أخرى.

4.12 قفل الأطفال

استخدم وظيفة قفل الأطفال لمنع الأطفال من العبث بالغسالة. وهكذا يمكنك تجنب أي تغييرات في تشغيل البرنامج.

إذا تم تدوير مقبض اختيار البرامج أثناء تنشيط قفل الأطفال، تظهر "Con" على الشاشة. لا يسمح قفل الأطفال بأي تغيير في البرنامج ودرجة الحرارة المحددة والسرعة والوظائف الإضافية.

4.9 جدول البرامج والاستهلاك

AR								وظيفة مساعدة					
الالبرنامج		الحد الأقصى للحمل (كجم)	مدة البرنامج (دقيقة)	استهلاك المياه (لتر)	استهلاك الطاقة (كيلو وات ساعة)	السرعة القصوى ***	الغسيل المبدئي	الغسيل السريع	الشطف المضاعف	ضد التجعيد	إيقاف الشطف	نطاق درجة حرارة قابل للاختيار درجة مئوية
قطن	90	5	147	66	2.25	1600	•	•	•	•	•	باردء90-
قطن	60	5	118	66	1.45	1600	•	•	•	•	•	باردء90-
قطن	40	5	98	66	0.85	1600	•	•	•	•	•	باردء90-
قطن اقتصادي	**60	5	151	47	0.85	1600	•	•	•	•	•	40-60
يومي سريع	90	5	88	55	1.90	1400			•		•	باردء90-
يومي سريع	60	5	58	55	1.00	1400			•		•	باردء90-
يومي سريع	30	5	28	55	0.20	1400			•		•	باردء90-
غسيل الملابس الملونة الداكنة	40	2.5	107	58	0.45	800			*		•	باردء40-
غسيل مختلط في درجة 40 (Mix 40)	40	3	115	45	0.50	800	•	•	•	•	•	باردء40-
غسيل يدوي	30	1	43	30	0.15	600						باردء30-
أصواف	40	1.5	60	40	0.30	600			•		•	باردء40-
(BabyProtect)واقي الطفل	90	5	165	85	1.90	1600	•		*		•	30-90
ألياف صناعية	60	2.5	116	45	0.90	800	•	•	•	•	•	باردء60-
ألياف صناعية	40	2.5	106	45	0.42	800	•	•	•	•	•	باردء60-

• قابل للتحديد
* يتم تحديده تلقائيًا. غير قابل للإلغاء.
** برنامج علامة الطاقة (EN 60456)
*** إذا كانت سرعة العصر أقل، يمكنك الاختيار إلى أن يتم الوصول إلى أقصى سرعة للعصر.

قد تختلف الوظائف الإضافية في الجدول وفقًا لطراز الغسالة.

قد تختلف قدرة استهلاك الماء والكهرباء تبعًا للتغييرات في ضغط الماء، ودرجة عسر الماء ودرجة حرارة الماء ودرجة حرارة البيئة المحيطة ونوع وكمية حمولة الغسيل، وتبعًا لاختيار الوظائف الإضافية وسرعة العصر والتغيرات في جهد الكهرباء.

يمكنك رؤية وقت الغسيل للبرنامج الذي قمت بتحديده على شاشة الغسالة. من الطبيعي حدوث اختلافات بسيطة بين الوقت المعروض على الشاشة ووقت الغسل الفعلي نظرًا للأسباب الموضحة أعلاه.

إذا لم يصل البرنامج لخطوة التسخين، يمكنك تغيير درجة الحرارة دون تبديل الغسالة إلى وضع Pause (الإيقاف المؤقت).

4.8 تحديد سرعة العصر

عند تحديد برنامج جديد، يتم عرض سرعة عصر الموصى بها للبرنامج المحدد على مؤشر سرعة العصر.
لخفض سرعة العصر، اضغط على زر Spin Speed Adjustment (ضبط سرعة العصر). يتم خفض سرعة العصر بشكل تدريجي. بعد ذلك، بناء على طراز الغسالة، تظهر الخيارات "Rinse Hold" (إيقاف الشطف) و"No Spin" (بدون عصر) على الشاشة. راجع قسم "اختيار الوظائف الإضافية" لشرح هذه الخيارات.

إذا لم يصل البرنامج لخطوة العصر، يمكنك تغيير السرعة دون تبديل الغسالة إلى وضع Pause (الإيقاف المؤقت).

4.2 إعداد الآلة
تأكد من إحكام ربط الخراطيم. قم بتركيب قابس الغسالة. افتح الصنبور بالكامل. ضع حمولة الغسيل في الغسالة. ضع مسحوق الغسيل ومُنعم الأنسجة.

4.3 اختيار البرنامج
حدد البرنامج المناسب للنوع، والكمية، ودرجة اتساخ وفقًا لـ "جدول الاستهلاك والبرنامج" وجدول درجات الحرارة أدناه.

90 درجة مئوية	الملابس المتسخة جدًا المصنوعة من القطن الأبيض والكتان. أغطية مناضد القهوة والمفارش والمناشف وأغطية السرائر إلخ)
60 درجة مئوية	يستخدم هذا البرنامج عادة للملابس القطنية أو الألياف الصناعية المتسخة الملونة ذات اللون الثابت (قميص، ملابس النوم، البيجامات، إلخ) والملابس البيضاء المتسخة قليلا (الملابس التحتية، إلخ)
40 درجة مئوية- 30 درجة مئوية- بارد	الملابس المصنوعة من خليط من الأنسجة بما فيها المنسوجات الناعمة (الستائر الشفافة، إلخ) والألياف الصناعية والأصواف.

حدد البرنامج المطلوب باستخدام زر "اختيار البرنامج".

برامج محددة بأعلى سرعة عصر مناسبة لهذا النوع المحدد من النسيج.

عند اختيار برنامج، راعي دائمًا نوع النسيج والألوان ودرجة الاتساخ ودرجة حرارة الماء المسموح بها.

قم دائمًا باختيار أقل درجة حرارة مطلوبة. حيث تمثل الحرارة العالية استهلاك أكثر للطاقة.

لمزيد من التفاصيل حول البرامج راجع "جدول الاستهلاك والبرنامج".

4.4 البرامج الرئيسية
وفقًا لنوع الأقمشة، استخدم البرامج الرئيسية التالية.

• قطن
استخدم هذا البرنامج للأقمشة القطنية (على سبيل المثال أغطية السرير واللحاف وأكياس المخدات والفوط وبرنس الحمام والملابس الداخلية وما إلى ذلك). يتم غسل حمولة الغسيل بحركات غسل قوية بالإضافة إلى دورة غسيل أطول.

• ألياف صناعية
استخدم هذا البرنامج مع الملابس المصنوعة من الألياف الصناعية (القمصان والبلوزات والملابس المصنوعة من خليط القطن/الألياف الصناعية وما إلى ذلك). فهو يغسل الملابس بحركات لطيفة ودورة غسيل قصيرة مقارنة ببرنامج الغسيل Cottons "الأقمشة القطنية". بالنسبة للستائر والأقمشة الشفافة، استخدم برنامج Synthetic 40°C "الألياف الصناعية 40 درجة" مع اختيار وظائف الغسلة التحضيرية وضد التجعد. حيث أن نسيجها الشبكي يسبب رغوة زائدة، اغسل الأقمشة الشفافة/الرقيقة بوضع القليل من المنظف في قسم الغسيل الرئيسي. لا ينبغي وضع المنظف في قسم مرحلة الغسلة التحضيرية.

• أصواف
استخدم هذا البرنامج لغسل الملابس الصوفية. حدد درجة الحرارة المناسبة التي تتوافق مع الملصقات على الملابس. استخدم منظفات مناسبة مع الملابس المصنوعة من الصوف.

4.5 البرامج الإضافية
تتوافر في الغسالة برامج إضافية للحالات الخاصة.

قد تختلف البرامج الإضافية في الجدول وفقًا لطراز الغسالة.

• قطن اقتصادي
يمكنك غسيل ملابسك المصنوعة الأقمشة االمتينة من الكتان والقطن بواسطة هذا البرنامج باستخدام الطاقة القصوى وتوفير المياه مُقارنة بجميع برامج الغسيل الأخرى المُناسبة للملابس القطنية. قد تختلف درجة الحرارة الفعلية للمياه عن درجة حرارة دورة الغسيل المُعلنة. يمكن تخفيض مدة البرنامج تلقائيًا خلال مراحل لاحقة من البرنامج عندما تغسل كمية أقل (مثال. نصف حمولة أو أقل) في هذه الحالة، سوف يقل استهلاك الكهرباء والمياه أكثر مما يمنحك الفرصة للمزيد من الغسيل الاقتصادي. وهذه الميزة مُتاحة في طرازات مُعينة تتمتع بميزة عرض الوقت المُتبقي.

• (BabyProtect)واقي الطفل
استخدم هذا البرنامج لغسيل ملابس الأطفال والملابس التي يرتديها أشخاص مصابون بالحساسية. وقت تسخين أطول وخطوة شطف إضافية توفر مستوى أعلى من الغسيل الصحي.

• غسيل يدوي
استخدم هذا البرنامج لغسل الملابس الصوفية/الرقيقة التي تحمل علامات "غسيل بدون استخدام الغسالة" والتي يفضل غسلها يدويًا. حيث يقوم البرنامج بالغسل بحركات غسل لطيفة لكي لا يتلف الملابس.

• يومي سريع
استخدم هذا البرنامج للغسل السريع لكمية صغيرة من الملابس القطنية قليلة الاتساخ.

• غسيل الملابس الملونة الداكنة
استخدم هذا البرنامج لغسيل الملابس الملونة الداكنة أو الملابس الملونة التي لا تريد أن تبهت ألوانها. يتم القيام بالغسيل بحركات ميكانيكية أقل وبدرجات حرارة أقل. يوصى باستخدام منظف سائل أو شامبو غسيل الأصواف للملابس الملونة الداكنة.

• غسيل مختلط في درجة 40)40 Mix(
استخدم هذا البرنامج لغسل الملابس القطنية والمصنوعة من الألياف الصناعية معًا دون فصلهما.

4.6 البرامج الخاصة
يمكنك اختيار أي من البرامج التالية للتطبيقات الخاصة.

• شطف
استخدم هذا البرنامج عند الرغبة في الشطف أو التنشية بشكل منفصل.

• عصر + مضخة
استخدم هذا البرنامج لعمل دورة عصر إضافية للغسيل أو لتصريف الماء من الغسالة.
قبل اختيار هذا البرنامج، حدد سرعة العصر المطلوبة واضغط على زر "Start/Pause" (بدء/توقف مؤقت). أولاً سوف تصرف الغسالة الماء الموجود بداخلها. ثم، سوف تقوم بعصر الملابس بسرعة العصر المحددة وتقوم بتصريف المياه الناتجة منها.
إذا رغبت فقط في تصريف الماء دون عصر الغسيل، فحدد برنامج Pump+Spin (العصر والطرد)، ثم حدد وظيفة "عدم العصر" باستخدام زر Speed Adjustment ضبط سرعة العصر. اضغط على الزر Start/Pause (بدء/توقف مؤقت).

استخدم سرعة عصر أقل مع الأقمشة الرقيقة.

4.7 تحديد درجات الحرارة
عند اختيار برنامج جديد يتم عرض درجة الحرارة المناسبة لهذا البرنامج على مؤشر درجة الحرارة.
لخفض درجة الحرارة، اضغط على زر Temperature Adjustment (ضبط درجة الحرارة). سوف تقل درجة الحرارة تدريجيًا.

4.1 لوحة التحكم



1- مقبض اختيار البرنامج (الوضع العلوي On/Off تشغيل/إيقاف تشغيل)
2- مؤشر متابعة البرنامج
3- زر ضبط درجة الحرارة
4- زر ضبط سرعة العصر
5- أزرار الوظائف الإضافية
6- زر البدء المتأخر (في بعض الطرازات)
7- زر Start/Pause (بدء/توقف مؤقت)



- عند استخدام مواد التبييض المصنوعة من الأكسجين، اختر البرنامج الذي يغسل بدرجة حرارة منخفضة.
- يمكن استخدام مواد التبييض المستندة إلى الأكسجين مع المنظفات؛ ومع ذلك، إذا كانت سيلوتها تختلف عن المنظف، فضع المنظف أولاً في القسم رقم "2" في درج المنظف وانتظر حتى يتدفق المنظف أثناء سحب الغسالة للماء. أضف مواد التبييض من نفس القسم أثناء استمرار الغسالة في سحب الماء.

استخدام مزيل الرواسب

- عند اللزوم، استخدم مزيلات الرواسب فقط المصنعة خصيصًا للغسالات.

3.8 إرشادات للغسيل الجيد

		الملابس			
		الألوان الفاتحة والملابس البيضاء	الألوان	الألوان الداكنة	Delicates "الملابس الرقيقة"/ Woolens "الأصواف/ الملابس الحريرية Silks
		(نطاق درجة الحرارة المُوصى بها بناء على مستوى الاتساخ: (40 - 90 درجة مئوية)	(نطاق درجة الحرارة المُوصى بها بناء على مستوى الاتساخ: بارد - 40 درجة مئوية)	(نطاق درجة الحرارة المُوصى بها بناء على مستوى الاتساخ: بارد - 40 درجة مئوية)	(نطاق درجة الحرارة المُوصى بها بناء على مستوى الاتساخ: بارد - 30 درجة مئوية)
مستوى الاتساخ	اتساخ شديد (بقع صعبه مثل العشب والقهوة والفواكه والدم.)	قد يكون من الضروري مُعالجة البقع مُسبقًا أو القيام بغسيل تحضيري. يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس البيضاء بالمقادير المُوصى بها مع الملابس شديدة الاتساخ. كما يوصى باستخدام مسحوق الغسيل لتنظيف بقع الطين والتربة والبقع الحساسة لمواد التبييض.	يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس الملونة بالمقادير المُوصى بها مع الملابس شديدة الاتساخ. كما يوصى باستخدام مسحوق الغسيل لتنظيف بقع الطين والتربة والبقع الحساسة لمواد التبييض. استخدم مساحيق الغسيل فقط دون مواد التبييض.	يمكن استخدام المُنظفات السائلة المُناسبة مع الملابس الملونة والداكنة بالمقادير المُوصى بها مع الملابس شديدة الاتساخ.	يُفضل استخدام المُنظفات السائلة المُخصصة للملابس الرقيقة. يجب غسل الملابس الصوفية والحريرية بمُنظفات خاصة بالملابس الصوفية.
	مستوى الاتساخ العادي (على سبيل المثال. البقع الناتجة من الجسم على الياقات والأساور)	يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس البيضاء بالمقادير المُوصى بها مع الملابس في مستوى الاتساخ العادي.	يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس الملونة بالمقادير المُوصى بها مع الملابس في مستوى الاتساخ العادي. استخدم مساحيق الغسيل فقط دون مواد التبييض.	يمكن استخدام المُنظفات السائلة المُناسبة مع الملابس الملونة والداكنة بالمقادير المُوصى بها مع الملابس ذات مستوى الاتساخ العادي.	يُفضل استخدام المُنظفات السائلة المُخصصة للملابس الرقيقة. يجب غسل الملابس الصوفية والحريرية بمُنظفات خاصة بالملابس الصوفية.
	اتساخ خفيف (لا توجد بقع مرئية.)	يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس البيضاء بالمقادير المُوصى بها مع الملابس قليلة الاتساخ.	يمكن استخدام مسحوق الغسيل والمُنظفات السائلة الموصى بها مع الملابس الملونة بالمقادير المُوصى بها مع الملابس قليلة الاتساخ. استخدم مساحيق الغسيل فقط دون مواد التبييض.	يمكن استخدام المُنظفات السائلة المُناسبة مع الملابس الملونة والداكنة بالمقادير المُوصى بها مع الملابس قليلة الاتساخ.	يُفضل استخدام المُنظفات السائلة المُخصصة للملابس الرقيقة. يجب غسل الملابس الصوفية والحريرية بمُنظفات خاصة بالملابس الصوفية.

3.7 استخدام مسحوق التنظيف والمُنعم

عند استخدام منظف، أو منعم، أو نشاء، أو صبغة نسيج، أو مواد تبييض، أو مزيل رواسب، يجب قراءة التعليمات الموجودة على العبوة بعناية واتباع قيم الكميات المقترحة. استخدم كوب المعايرة إن وجد.

درج مساحيق الغسيل

يتكون درج مساحيق التنظيف من ثلاثة أقسام:

- (1) للغسلة التحضيرية
- (2) للغسلة الرئيسية
- (3) للمنعمات
- (*) بالإضافة إلى ذلك، توجد قطعة سيفون في قسم المنعم.



مسحوق التنظيف والمُنعمات ومواد التنظيف الأخرى

- أضف مسحوق الغسيل والمُنعمات قبل بدء تشغيل برنامج الغسيل.
- لا تترك درج موزع مسحوق الغسيل مفتوحًا أثناء عمل برنامج الغسيل!
- عند استخدام أحد البرامج بدون الغسلة التحضيرية، لا ينبغي وضع مسحوق غسيل في قسم الغسلة التحضيرية (قسم رقم "1").
- عند استخدام أحد البرامج باستخدام الغسلة التحضيرية، لا ينبغي وضع أي منظف سائل في قسم الغسلة التحضيرية (قسم رقم "1").
- لا تقم باختيار برنامج مع الغسلة التحضيرية إذا كنت تستخدم كيس مسحوق أو كرة التوزيع. ضع حقيبة مسحوق الغسيل أو كرة التوزيع مباشرةً بين الغسيل في الغسالة.
- في حالة استخدام منظف سائل، لا تنسى وضع كأس المنظف السائل في قسم الغسيل الرئيسي (قسم رقم "2").

اختيار نوع مسحوق التنظيف

يعتمد نوع مسحوق الغسيل الذي يتم استخدامه على نوع الأنسجة وألوانها.

- استخدم مساحيق غسيل مختلفة للملابس الملونة والبيضاء.
- اغسل الملابس الرقيقة بمنظفات خاصة (منظف سائل، شامبو الصوف، إلخ.) تستخدم للملابس الرقيقة فقط.
- عند غسل الملابس والألحفة ذات الألوان الداكنة، يوصى باستخدام منظف سائل.
- اغسل الأصواف بمسحوق خاص بالأصواف.

تحذير: استخدم فقط مساحيق الغسيل المصنعة بشكل مخصوص للغسالات.

تحذير: لا تستخدم الصابون المبشور.

ضبط كمية المسحوق

تعتمد كمية مسحوق الغسيل الذي يتم استخدامه على كمية الغسيل ودرجة الاتساخ وعسر الماء.

- لا تستخدم كميات تتجاوز كميات المقادير الموصى بها على عبوة المنظف لتفادي مشكلات الرغوة الزائدة والشطف السيء، علاوة على توفير المال وحماية البيئة.
- استخدم كميات منظف أقل للكميات الصغيرة أو الملابس الأقل اتساخًا.

استخدام المنعمات

ضع المُنعم في قسم المُنعمات بدرج مسحوق الغسيل.

- لا تتجاوز مستوى علامة (<max>) الموجودة في قسم المنعم.
- إذا فقد المُنعم سيولته، فقم بتخفيفه بالماء قبل وضعها في درج مسحوق التنظيف.

استخدام مساحيق غسيل سائلة

إذا كانت الغسالة مزودة بكأس المنظف السائل:

- +تأكد من وضع علبة المنظف السائل في قسم رقم "2".
- إذا فقد المنظف السائل سيولته، فقم بتخفيفه بالماء قبل وضعها في كأس المنظف.



إذا كانت الغسالة غير مزودة بكأس المنظف السائل:

- لا تستخدم مسحوق التنظيف السائل للغسلة التحضيرية في برنامج الغسلة التحضيرية.
- +يحدث المنظف السائل البقع في الملابس عند استخدامه مع وظيفة البدء المتأخر. إذا كنت تريد استخدام وظيفة البدء المتأخر، فلا تستخدم المنظف السائل.

استخدام الجل و منظفة الأقراص

قم بتطبيق التعليمات عن استخدام الأقراص، والجل، والمنظفات المماثلة.

- إذا كان المنظف الجل يميل إلى السيولة ولا تحتوي الغسالة على كأس المنظف السائل الخاص، ضع المنظف الجل في قسم منظف الغسلة الرئيسية أثناء دخول الماء للمرة الأولى. إذا كانت الغسالة مزودة بكأس المنظف السائل، فاملأ المنظف في هذا الكأس قبل بدء البرنامج.
- إذا كان المنظف الجيل لا يميل للسيولة أو إذا كان على هيئة قرص كبسولة سائلة، فضعه في الاسطوانة مباشرة قبل الغسيل.
- ضع المنظفات الأقراص في صندوق الغسيل الرئيسي (الصندوق رقم: "2") أو مباشرة في الحلة قبل الغسيل.

يمكن أن تترك أقراص المنظفات بقايا في قسم المنظف. عند مصادفة هذه الحالة، ضع الأقراص بين الغسيل. وأغلق الجزء السفلي من الاسطوانة في مرات الغسل القادمة.

استخدم المنظف الجل أو السائل بدون تحديد وظيفة الغسلة التحضيرية.

استخدام النشاء

- قم بإضافة نشاء سائل، أو مسحوق نشاء، أو صبغة النسيج في قسم المنعم.
- لا تستخدم المُنعم والنشاء معًا في نفس دورة الغسيل.
- ○امسح داخل الغسالة بقطعة قماش نظيفة ومبللة بعد استخدام النشاء.

استخدام مواد التبييض

- حدد برنامج مع الغسلة التحضيرية وأضف مواد التبييض في بداية الغسلة التحضيرية. لا ينبغي وضع المنظف في قسم مرحلة الغسلة التحضيرية. وكتطبيق بديل، حدد برنامج مع تصريف زائد وأضف مواد التبييض أثناء سحب الغسالة للماء من قسم المنظف أثناء خطوة التصريف الأولى.
- لا تستخدم مواد التبييض والمنظف مخلوطين.
- استخدم كمية قليلة فقط (50 مل تقريبًا) من مواد التبييض وقم بتصريف المياه من الملابس جيدًا حيث أنها تسبب تهيج الجلد. لا تصب مواد التبييض على الملابس ولا تستخدمها مع الملابس الملونة.

3 الإعداد

3.1 تصنيف الغسيل

- قم بتصنيف الغسيل وفقًا لنوع الأنسجة واللون ودرجة الاتساخ ودرجة حرارة الماء المسموح بها.
- اتبع دومًا التعليمات الموجودة بملصقات الأثواب.

3.2 تجهيز الملابس للغسيل

- تعمل الملابس والمغسولات المرفق بها مواد معدنية مثل الصدريات التحتية وإبزيم الأحزمة والأزرار المعدنية على إتلاف الغسالة. قم بإزالة الأجزاء المعدنية أو اغسل الملابس عن طريق وضعها في كيس الغسيل أو كيس مخدة.
- أخرج جميع المواد بالجيوب مثل العملات، والأقلام، ومشابك الأوراق واقلب الجيوب من الداخل للخارج ونظفها. قد تتسبب هذه الأشياء في تلف الغسالة وتتسبب في مشكلة ضوضاء.
- ضع الملابس صغيرة الحجم مثل جوارب الأطفال والجوارب النايلون في كيس غسيل أو كيس مخدة.
- ضع الستائر داخل الغسالة دون الضغط عليها. أزل الأشياء الملحقة بالستائر.
- أغلق السوست (الأبازيم) وقم بتثبيت الأزرار غير المحكمة وإصلاح الثقوب والتمزقات.
- قم بغسل المنتجات المميزة بملصقات "قابلة للغسيل بالغسالة" أو "تغسل يدويًا" باستخدام البرنامج المناسب.
- لا تغسل الملابس الملونة مع الملابس البيضاء. فالملابس القطنية الجديدة ذات الألوان الداكنة تطلق الكثير من الصبغة. لذا، قم بغسلها وحدها.
- ينبغي التعامل مع البقع العنيدة بشكل مناسب قبل غسلها. إذا كنت غير متأكد فتحقق مع منظف الملابس بالبخار.
- استخدم مغيرات الصبغات/الألوان ومزيلات الرواسب المناسبة للغسيل في الغسالة. واتبع دومًا الإرشادات الموجودة على العبوة.
- قم بغسل البنطلونات والملابس الرقيقة بعد قلبها على الظهر.
- احتفظ بالملابس المصنوعة من صوف وبر الأنقرة في الفريزر لبضع ساعات قبل الغسيل. حيث سيعمل هذا الحد من تكون الوبر.
- يجب تخليص الغسيل الذي تعرض بكثافة لمواد مثل الدقيق أو الغراء أو مسحوق اللبن إلخ من هذه المواد قبل وضعه في الغسالة. قد تتجمع هذه الأتربة والمساحيق الموجودة على الغسيل على الأجزاء الداخلية للغسالة وتتسبب في عطلها.

3.3 أشياء ينبغي فعلها لتوفير الكهرباء

سوف تساعدك المعلومات التالية على استخدام الغسالة بصورة صديقة للبيئة وموفرة للطاقة.

- قم بتشغيل الغسالة بإعداد أقصى سعة يسمح بها البرنامج الذي قمت بتحديده، ولكن لا تضع حمولة زائدة؛ راجع، "جدول الاستهلاك والبرنامج".
- اتبع دائمًا الإرشادات الموضحة على عبوة المسحوق.
- قم بغسل الملابس قليلة الاتساخ في درجات حرارة منخفضة.
- استخدم برامج سريعة للكميات الصغيرة من الملابس قليلة الاتساخ.
- لا تستخدم الغسل التحضيري ودرجات الحرارة العالية لغسل الملابس قليلة الاتساخ أو البقع.
- إذا كنت ترغب في تجفيف الملابس في مجفف، فاختر أعلى سرعة دوران عصر موصى بها أثناء الغسيل.
- لا تستخدم مسحوق غسيل بكمية زائدة عن الكمية الموصى بها على عبوة المسحوق.

3.4 الاستخدام الأولي

قبل البدء في استخدام الغسالة، تأكد من القيام بجميع التحضيرات بما يتفق مع التعليمات في قسمي "معلومات السلامة الهامة" و"التركيب". لتجهيز الغسالة للغسيل، قم بالتشغيل أولاً في برنامج "تنظيف الحلة". إذا كانت الغسالة غير مجهزة ببرنامج "تنظيف الاسطوانة"، قم بتنفيذ إجراء "الاستخدام الأولي بما يتفق مع الأساليب الموصوفة في القسم "5.2 تنظيف باب التحميل والاسطوانة" في دليل المستخدم.



استخدم مضاد الرواسب المناسب للغسالات.

قد يتبقى بعض الماء في الغسالة نتيجة عمليات مراقبة الجودة. لا يعد هذا الأمر مضرًا بالغسالة.

3.5 سعة التحميل الصحيحة

تعتمد أقصى سعة تحميل على نوع الملابس ودرجة الاتساخ وبرنامج الغسيل المطلوب.
تضبط الغسالة كمية الماء وفقًا لكمية الغسيل الموضوعة بداخلها أوتوماتيكيًا.

تحذير: اتبع الإرشادات الواردة في "جدول البرنامج والاستهلاك". عند وضع حمل زائد بالغسالة يضعف أداء الغسالة. بالإضافة إلى ذلك، قد تحدث مشكلات الاهتزاز والضوضاء.

نوع الغسيل	الوزن (بالجرام)
برنس الحمام	1200
المناديل	100
اللحافات	700
الملاءات	500
أكياس الوسائد	200
أغطية الموائد	250
المناشف	200
مناشف اليد	100
أثواب المساء	200
الملابس الداخلية	100
الأفرول الرجالي (ملابس العمل)	600
القمصان الرجالي	200
البيجاما الرجالي	500
البلوزات	100

3.6 تحميل الغسيل

1. افتح باب تحميل الغسيل.
2. ضع الغسيل في الجهاز.
3. ادفع الباب لإغلاقه حتى تسمع صوت قفل. وتأكد من عدم تعلق أي شيء بالباب.

يتم قفل باب التحميل أثناء تشغيل البرنامج. يمكن فتح الباب فقط بعد فترة قصيرة من انتهاء البرنامج.

تحذير: في حالة الخطأ في وضع الغسيل، قد تحدث ضوضاء أو اهتزاز في الغسالة.

أغلق الصنبور وأزل الصمولة. أعد ربط الصامولة بإحكام بعد الكشف على العازل. لتفادي أي تسرب للماء وأي تلفيات أخرى قد تنتج عن ذلك، أغلق الصنابير عندما لا تكون الغسالة مستخدمة.

2.5 التوصيل بمنفذ التصريف

- ينبغي توصيل طرف خرطوم التصريف مباشرة بمنفذ تصريف الماء المستهلك أو بحوض الوجه.

تحذير: قد يُغمر منزلك بالماء إذا انفلت الخرطوم من مبيته أثناء تصريف الماء. علاوة على ذلك، ولكن يرجى الانتباه إلى خطر الإصابة بحروق بسبب درجات حرارة الغسيل المرتفعة! لتجنب هذه المواقف وللتأكد من دخول وتصريف الماء بسهولة من الغسالة، ثبت نهاية خرطوم التصريف بإحكام بحيث لا يمكن انفلاته.

- ويجب توصيل الخرطوم على ارتفاع 40 سم على الأقل و100 سم كحد أقصى.
- في حالة رفع الخرطوم بعد وضعه على مستوى الأرضية أو بالقرب من الأرض (بما لا يقل عن 40 سم أعلى الأرض)، فسوف يصبح التصريف صعبًا ويخرج الغسيل مبتلاً بشدة. لذا يرجى اتباع الارتفاعات المحددة في الرسم.



- لمنع رجوع الماء المتسخ إلى الغسالة ولجعل عملية التصريف أكثر سهولة، ينبغي تجنب إدخال طرف الخرطوم في منفذ التصريف أكثر من 15 سم. وإذا كان الخرطوم طويلاً فقم بتقصيره.
- ينبغي تجنب ثني طرف الخرطوم أو المشي فوقه أو انحشاره بين منفذ التصريف والغسالة.
- إذا كان الخرطوم قصيرا جدًا، فاستخدمه بإضافة خرطوم تطويل أصلي. يجب ألا يزيد طول الخرطوم عن 3.2 متر. ولتجنب الأعطال الناجمة عن تسرب الماء، يجب تثبيت الوصلة بين خرطوم التطويل وخرطوم التصريف بإحكام بالاستعانة بمشبك ملائم حتى لا تنحل ويحدث التسرب.

2.6 ضبط الأرجل

تحذير: يجب أن توضع غسالتك في وضع مستوي ومتوازن على أقدامها حتى تعمل بصمت وبدون اهتزاز. قم بموازنة الجهاز عن طريق ضبط الأقدام. وإلا، فقد تتحرك الغسالة من مكانها وتسبب مشكلات التصادم والاهتزاز.



1. قم بفك صواميل القفل عند الأقدام يدويًا.
2. قم بضبط الأرجل حتى تستوي الغسالة ومتزنة.
3. أحكم ربط صواميل القفل مرة أخرى يدويًا.



تحذير: لا تستخدم أي أدوات لفك صواميل القفل. وإلا فقد تتعرض للتلف.

2.7 التوصيل الكهربي

قم بتوصيل المنتج بمنفذ مؤرض محمي بصمام كهربي 16 أمبير. لن تكون الشركة مسئولة عن أي تلفيات قد تنشأ عند استخدام الغسالة بدون طرف أرضي بما يتفق مع اللوائح المحلية.

- ينبغي أن يتوافق التوصيل مع التشريعات المحلية.
- ويجب أن يظل قابس كبل الطاقة في مكان سهل الوصول إليه بعد التركيب.
- إذا كانت القيمة الحالية للمصهر أو قاطع التيار في الخرطوم أقل من 16 أمبير، فاستخدم كهربائي مؤهل لتركيب مصهر 16 أمبير.
- الجهد الكهربي المحدد في قسم "المواصفات الفنية" يجب أن يكون مساويًا للجهد الكهربي للموصلات الرئيسية.
- لا تقم بعمل التوصيلات عبر كابلات تطويل أو قوابس متعددة.

تحذير: يجب استبدال كابل الطاقة التالف بواسطة وكيل خدمة معتمد.

نقل المنتج

1. افصل الغسالة قبل نقلها.
2. قم بإزالة وصلات إمداد وتصريف الماء.
3. قم بتصريف الماء المتبقي في الغسالة.
4. قم بتركيب مسامير تأمين النقل بالترتيب العكسي لعملية الإزالة؛

لا تقم مطلقًا بتحريك الغسالة بدون تثبيت مسامير تأمين النقل في مواضعها جيدًا!

تحذير: تعد مواد التغليف خطرة على الأطفال. ضع مواد التغليف في مكان آمن بعيدًا عن متناول الأطفال.

2 التركيب

استعن بأقرب وكيل خدمة معتمد لتركيب المنتج. ليصبح المنتج جاهز للاستخدام، راجع المعلومات في دليل المستخدم وتأكد من أن أنظمة الكهرباء وإمداد الماء تصريفه مناسبة قبل الاتصال بمركز الخدمة المعتمد. وإذا لم تكن كذلك، فيُرجى الاتصال بفني وسباك مؤهلين للقيام بأي تعديلات ضرورية.

إعداد المكان والتجهيزات الكهربية وتجهيزات إمداد الماء وتصريفه في مكان التركيب يعد من مسئولية العميل.
تحذير: يجب أن يقوم مركز الخدمة المعتمد بالتركيب والتوصيلات الكهربية للمنتج. جهة الصنع غير مسؤولة عن الأعطال المترتبة على إجراءات يقوم بها شخص غير معتمد.
تحذير: قبل التركيب، يجب التأكد بصريًا من خلو المنتج من العيوب. وفي حالة وجود عيوب لا تقم بتركيبه، يمكن أن تمثل المنتجات التالفة خطرًا على سلامتك.
تأكد من عدم انثناء مدخل الماء وخراطيم التصريف وأيضًا كبل الطاقة، أو انحشارها أو تشققها أثناء دفع المنتج في مكانه بعد إجراءات التركيب أو التنظيف.

2.1 المكان الملائم للتركيب

- ضع الغسالة على أرض صلبة. لا تضع الغسالة على بساط ذي وبر طويل أو على أي أسطح مشابه لذلك.
- قد يصل الوزن الإجمالي للغسالة والمجفف -في حالة امتلائهما- ووضعهما فوق بعض إلى 180 كجم تقريبًا. ضع الغسالة على أرضية صلبة وثابتة تستطيع تحمل ثقل الغسالة!
- لا تضع الغسالة فوق كبل الطاقة.
- لا تقوم بتركيب الغسالة في مكان يحتمل أن تهبط درجة حرارته إلى 0 درجة مئوية.
- ضع الغسالة على بعد 1 سم على الأقل من حواف قطع الأثاث الأخرى.

2.2 إزالة دعامة التغليف

أمل الغسالة للخلف لإزالة دعامة التغليف. أزل دعامة التغليف عن طريق سحب الشريط.

2.3 إزالة أقفال تأمين النقل

تحذير: لا تقم بإزالة أقفال تأمين النقل قبل نزع دعامة التغليف.
تحذير: قم بإزالة أحزمة الأمان للنقل قبل تشغيل الغسالة! وإلا فقد تتعرض للتلف.

1. قم بفك كافة المسامير بواسطة مفتاح ربط المسامير حتى تدور بسهولة (C).
2. أزل مسامير تأمين النقل عن طريق إدارتها برفق.
3. قم بتركيب الأغطية الملحقة بحقيبة دليل المستخدم داخل الفتحات الموجودة باللوحة الخلفية. (P)



احتفظ بمسامير تأمين النقل بمكان آمن لإعادة استخدامها عند الحاجة إلى نقل الغسالة مجددًا في المستقبل.
لا تقم مطلقًا بتحريك الغسالة بدون تثبيت مسامير تأمين النقل في مواضعها جيدًا!

2.4 توصيل مصدر إمداد الماء

ضغط إمداد الماء المطلوب لتشغيل الغسالة يتراوح من 1 إلى 10 بار (0.1 – 1 مللي باسكال). يلزم تدفق من 10 إلى 80 لتر ماء في الدقيقة من الصنبور مفتوح بشكل كامل لكي تعمل الغسالة بطريقة سلسة. قم بتوصيل صمام خفض ضغط الماء إن كان ضغط الماء أعلى من ذلك.
إذا كنت تعتزم استخدام الغسالة ذات مدخل الماء المزدوج كوحدة بمدخل ماء واحد (بارد فقط)، فعليك تركيب السدادة المتوفرة مع الغسالة في صمام الماء الساخن قبل تشغيل الغسالة. (ينطبق هذا على الغسالات المزودة بمجموعة سدادات غير نافذة.)
تحذير: ويراعى عدم توصيل الغسالات ذات منفذ دخول الماء الفردي بصنبور الماء الساخن. وفي هذه الحالة سيتلف الغسيل أو ستتحول الغسالة إلى وضع الحماية ولن تعمل.
تحذير: لا تستخدم خراطيم مداخل الماء القديمة أو المستخدمة في الغسالة الجديدة. حيث أنها قد تتسبب في حدوث بقع بالملابس.

1. قم بتوصيل الخراطيم الخاصة الملحقة مع الغسالة بصمامات دخول الماء بالغسالة. الخرطوم المميز باللون الأحمر (يسار) (بحد أقصى 90 درجة مئوية) مخصص لفتحة دخول الماء الساخن، والخرطوم المميز باللون الأزرق (يمين) (بحد أقصى 25 درجة مئوية) مخصص لفتحة دخول الماء البارد.



تحذير: عند تركيب الغسالة، تأكد من صحة تركيب توصيلات الماء الساخن والماء البارد. حيث قد يتسبب التوصيل غير الصحيح في خروج الغسيل ساخنًا في نهاية عملية الغسيل مما يتسبب في تآكله.

2. قم بربط جميع صواميل الخراطيم باليد. لا تستخدم أداة عند ربط الصواميل.



3. افتح الصنابير بالكامل بعد توصيل الخرطوم للتحقق من عدم وجود تسرب للماء عند الوصلات. وفي حالة وجود أي تسريب

1 تعليمات هامة للسلامة والبيئة

يحتوى هذا القسم على إرشادات السلامة التي تساعد في الحماية من الإصابات الشخصية والأضرار المادية. وقد يؤدي عدم إتباع هذه الإرشادات إلى إلغاء الضمان.

1.1 السلامة العامة

- يمكن استخدام هذا المنتج بواسطة الأطفال في سن الثامنة وما فوقه وبواسطة الأشخاص ممن يعانون ممن لا يتمتعون بقدرات بدنية، أو حسية، أو عقلية كاملة أو ممن لم يمارسوا أو يعرفوا تشغيل المنتج بشرط أن يتم الإشراف عليهم أو تدريبهم على الاستخدام الآمن للمنتج والمخاطر التي قد يتسبب فيها. يجب على الأطفال عدم العبث بهذا المنتج. يجب ألا يقوم الأطفال بأعمال الصيانة والتنظيف إلا إذا كان يشرف عليهم شخص ما.
- لا تضع المنتج على أرضية مغطاة بالسجاد. وإلا، فإن النقص في تدفق الهواء أسفل الجهاز سوف يتسبب في ازدياد سخونة الأجزاء الكهربية. وهو ما قد يتسبب في حدوث مشكلات بالغسالة.
- إذا كانت الغسالة عاطلة، يجب ألا يتم تشغيلها إلا إذا تم تصليحها من قبل مركز صيانة معتمد. حيث إن ذلك ينطوي على خطر الإصابة بصدمة كهربية!
- هذه الغسالة مصممة للاستمرار في العمل في حالة رجوع التيار الكهربي بعد انقطاعه. إذا كنت تريد إلغاء البرنامج، راجع قسم "إلغاء البرنامج".
- قم بتوصيل المنتج بمنفذ مؤرض محمي بصمام كهربي 16 أمبير. لا تهمل تركيب التأريض بواسطة فني كهربائي مؤهل. لن تكون الشركة مسئولة عن أي تلفيات قد تنشأ عند استخدام الغسالة بدون طرف أرضي بما يتفق مع اللوائح المحلية.
- يجب التأكد من ربط خرطوم إمداد الماء وخرطوم التصريف وعدم تلفهما. وإلا، فإن هناك احتمال خطورة تسرب الماء.
- لا تفتح مطلقًا الباب أو تزيل الفلتر في حالة وجود ماء داخل حلة الغسالة. وإلا، فسيحدث خطر انسكاب الماء الساخن أو الإصابة منه.
- لا تفتح باب التحميل القفل عنوة مطلقًا. سيكون باب التحميل جاهزًا للفتح بعد دقائق قليلة من انتهاء دورة الغسيل. في حالة فتح باب التحميل عنوة، فقد تتلف ميكانيكية القفل والباب.
- افصل قابس الغسالة عند عدم استخدمها.
- لا تغسل الغسالة بصب الماء فوقها أو رش الماء عليها مطلقًا! حيث إن ذلك ينطوي على خطر الإصابة بصدمة كهربية!
- لا تلمس القابس مطلقًا بيد مبتلة! لا تفصل القابس مطلقًا عن طريق جذب الكبل، ولكن عن طريق جذب القابس نفسه.
- استخدم المنظفات والمُنعمات والمواد الإضافية المناسبة للغسالات الأتوماتيكية فقط.
- اتبع التعليمات على علامات المنسوجات وعلى عبوات المنظف.
- يجب فصل الغسالة أثناء إجراءات التركيب، والصيانة، والتنظيف، والإصلاح.
- يقوم **مركز الخدمة المعتمد** دائمًا بإجراءات التركيب والإصلاح. جهة الصنع غير مسؤولة عن الأعطال المترتبة على إجراءات يقوم بها شخص غير معتمد.
- في حالة تلف كبل الطاقة، يجب استبداله بواسطة الشركة المصنعة، أو خدمة ما بعد البيع، أو شخص لديه نفس المؤهلات (ويفضل أن يكون فني كهرباء)، أو شخص ما يعينه المستورد لتجنب المخاطر المحتملة.

1.2 الغرض من الاستخدام

- هذا المنتج مصمم للاستخدام المنزلي. وغير مناسب للاستخدام التجاري ويجب ألا يستخدم في غير الغرض المخصص له.
- تستخدم هذه الغسالة فقط لغسل وتجفيف الملابس المحددة في هذا الدليل.
- تخلي جهة الصنع طرفها من أي مسؤولية مترتبة على الاستخدام أو النقل غير الصحيح.

1.3 سلامة الأطفال

- تعد مواد التغليف خطرة على الأطفال. ضع مواد التغليف في مكان آمن بعيدًا عن متناول الأطفال.
- الأجهزة الكهربية خطرة على الأطفال. لذا، ابق الأطفال بعيدًا عن الغسالة أثناء تشغيلها. ولا تسمح لهم بالعبث في الغسالة. استخدم قفل الأطفال لمنع الأطفال من العبث بالغسالة.
- لا تنسى إغلاق باب التحميل عند ترك مكان وجود الغسالة.
- قم بتخزين كافة المنظفات والإضافات في مكان آمن بعيدًا عن متناول الأطفال وذلك من خلال إغلاق غطاء حاوية المنظفات أو إقفال علبة المنظفات.

1.4 معلومات العبوة

- تم تصنيع مواد التعبئة الخاصة بالمنتج من مواد قابلة لإعادة التدوير بما يتفق مع "قوانين البيئة القومية". لا تتخلص من مواد التعبئة مع النفايات المنزلية أو النفايات الأخرى. عليك أن تأخذها إلى مراكز تجميع مواد التعبئة المخصصة بواسطة الجهات المحلية.

1.5 التخلص من نفايات المنتج

- تم تصنيع هذا المنتج باستخدام أجزاء ومواد عالية الجودة يمكن إعادة استخدامها بالإضافة إلى مناسبة لإعادة التدوير. ولذا، لا تتخلص من هذا المنتج مع النفايات المنزلية العادية في نهاية صلاحيته للعمل. وعليك أن تأخذه إلى مركز تجميع خاص بإعادة تدوير الأجهزة الكهربية والإلكترونية. يرجى استشارة الجهات المحلية لمعرفة أقرب مركز تجميع. ساعد في الحفاظ على البيئة والموارد الطبيعية من خلال إعادة تدوير المنتجات المستخدمة. لسلامة الأطفال، اقطع كبل الطاقة واكسر القطعة الميكانيكية لقفل باب التحميل بحيث يكون معطلا قبل التخلص من المنتج.

1.6 الالتزام بتوجيهات WEEE

مواد التعبئة لهذا الجهاز قابلة لإعادة التدوير. ساعد بإعادة تدويره واحمي البيئة بإلقاه في صناديق قمامة البلدية المجهزة لهذا الغرض. يحتوي جهازك أيضاً على مقدار كبير من المواد القابلة لإعادة التدوير. عليها علامة بهذا الملصق للإشارة غلى أن الأجهزة المستخدمة لا ينبغي خلطها مع القمامة الأخرى. بهذه الطريقة، سيتم إجراء إعادة تدوير الجهاز بتنظيم من جهة التصنيع تحت أفضل ظروف ممكنة، وذلك بالالتزام بالتوجيهات الأوروبية EC/2002/96 بشأن نفايات الأجهزة الكهربائية والإلكترونية. اتصل بصالة مدينتك أو بائع التجزئة لمعرفة أقرب نقاط جمع الأجهزة المستخدمة لمنزلك. نشكرك على أداء واجبك في المحافظة على البيئة.

WMB 50821
WMB 50821 S

الغسالة
دليل المستخدم



مقدمة من فيكو

2820523094_AR/070812.1611

BEKO